DOCUMENT RESUME

ED 267 225 CE 043 745

TITLE A Catalog of Performance Objectives and Performance

Guides for Laser Systems Technician for the Job

Titles of Laser Technician D.O.T. 019.181-010, Laser

Systems Technician D.O.T.-N/A.

INSTITUTION Associated Educational Consultants, Inc., Pittsburgh,

Pa.; Pennsylvania State Dept. of Education, Harrisburg. Bureau of Vocational and Technical

Education.

PUB DATE Jul 84 NOTE 186p.

PUB TYPE Guides - Non-Classroom Use (055)

EDRS PRICE MF01/PC08 Plus Postage.

DESCRIPTORS *Behavioral Objectives; Competence; Competency Based

Education; Equipment; Hand Tools; *Job Skills; Job

Training; *Lasers; Occupational Information;

*Paraprofessional Personnel; Postsecondary Education;


*Standards; Technical Education; *Technical

Occupations; Vocational Education

IDENTIFIERS Vocational Technical Education Consortium States

ABSTRACT

This catalog lists and describes the tasks performed by a laser technician and standards for their performance. Each duty contains performance objectives for related tasks. Included in the objectives are standards that must be met and conditions for performance of the tasks. Performance guides provided for each objective identify the conditions required to complete the task as well as a standard of occupation-related requirements for acceptable completion of the task. Tasks include maintaining records; installing, maintaining, and analyzing laser systems; and repairing temperature control systems, beam generation systems, excitation systems, low voltage power supply, RF systems, vacuum systems, and gas supply systems. The catalog also contains the following appendixes: the contents of the standard tool kit used by laser systems technicians; a listing by percent of use of those tools by surveyed incumbents; a bibliography of sources of standards cited in the catalog; a cross-reference table listing the duties and tasks as they appeared in the survey instrument; the disposition of duties and tasks within this catalog, and the results of the incumbent responses by number and percent performing; a bibliography of state-of-the-art references identified during the catalog development; and a graphic representation of the Vocational-Technical Education Consortium of States developmental model. (KC)





A CATALOG OF PERFORMANCE OBJECTIVES

AND PERFORMANCE GUIDES

FOR

LASER SYSTEMS TECHNICIAN

for the Job Titles of

Laser Technician D.O.T. 019.181-010 Laser Systems Technician D.O.T. - N/A

ASSOCIATED EDUCATIONAL CONSULTANTS, INC. North Allegheny Office and Research Park McKnight and Pine Creek Roads, P. O. Box 15073 Pittsburgh, Pennsylvania 15237

and

PENNSYLVANIA DEPARTMENT OF EDUCATION Bureau of Vocational Education Harrisburg, Pennsylvania 17126

July, 1984

U.S. DEPARTMENT OF EDUCATION NATIONAL INSTITUTE OF EDUCATION EDUCATIONAL RESOURCES INFORMATION CENTER (ERIC)

This document has been reproduced as received from the person or organization originating it

Minor changes have been made to improve reproduction suality

 Points of view or opinions stated in this docu ment do not necessarily represent official NIE position or policy

"PERMISSION TO REPRODUCE THIS

MATERIAL HAS BEEN GRANTED BY

TO THE EDUCATIONAL RESOURCES INFORMATION CENTER (ERIC) "

COPYRIGHT 1984 V-TECS



PROJECT PERSONNEL

Vernon Register, Curriculum & Exemplary Coordinator
Pennsylvania Department of Education
Bureau of Vocational Education
Harrisburg, Pennsylvania 17108

ASSOCIATED EDUCATIONAL CONSULTANTS, INC. North Allegheny Office and Research Park McKnight and Pine Creek Roads, P. O. Box 15073 Pittsburgh, Pennsylvania 15237

Dan K. Jacobs, Project Director

Judith H. Dallas, Research Assistant

Alice E. McKenna, Research Assistant

Ona Kay L. Kinter, Project Assistant

Marti Kersten, Administrative Assistant



USER'S NOTE

Every effort has been made to ensure that the material contained in this catalog was presented in the most generic format possible. Performance Guides were written as they would apply to most laser systems. However, because of the danger involved in using laser equipment, it is critical that professional and technical discretion be used when utilizing the catalog in any environment. All laser system service manuals and manufacturer's instructions must be carefully followed when performing any of the tasks included in this document. The steps in the performance guides contained in this catalog are those suggested by the Writing Team as applicable to most laser systems, but they may not apply to all laser systems. Consider first the instructions provided by the manufacturer before following the procedures outlined in this catalog.



iii

ACKNOWLEDGEMENTS

Whenever a project of this magnitude is approached, the cooperation of a large number of dedicated and talented people with a variety of expertise is required to complete the task successfully. Associated Educational Consultants, Inc., feels that this was accomplished in producing this high technology catalog entitled, <u>Catalog of Performance</u> Objectives and <u>Performance Guides</u> for Laser Systems Technician.

Among the many people to be thanked are the members of the writing team: Mr. Edward Chara, formerly with Lasermation of Philadelphia, Pennsylvania and now with Laser Systems of Baltimore, Maryland; Mr. Ross Macklin of Aero-Tech, Pittsburgh, Pennsylvania; and Mr. Thomas Schaeffler of Quantronix, Smithtown, New York.

The field review team which provided task validation and recommendations for revision of the Field Review Catalog was comprised of Mr. Ernest Prescott, Alcoa Industries, Pittsburgh, Pennsylvania; Mr. Herman Reedy, II-VI, Inc., Saxonburg, Pennsylvania; and Mr. Walter Dociey, Westinghouse Corporation, Pittsburgh, Pennsylvania.

Associated Educational Consultants, Inc., would also like to recognize the many laser systems technicians and their employers who cooperated in responding to the occupational inventory survey. Appreciation is also extended to the many individuals who responded to requests for information and assistance in assembling the state-of-the-art research.



Continuing throughout the project was the ready assistance provided by the discerning and always helpful members of the V-TECS Central Staff: Dr. Ron McCage and Dr. Charles Losh.

And last, but certainly not least, Associated Educational Consultants, expresses its sincere appreciation to the members of the staff in the Bureau of Vocational Education in the Pennsylvania Department of Education especially Mr. Vernon Register who served as V-TECS Technical Coordinator for this project.



TABLE OF CONTENTS

P	Page
PROJECT PERSONNEL	ii
USER'S NOTE i	iii
ACKNOWLEDGEMENTS	iv
TABLE OF CONTENTS	ίv
INTRODUCTION	ix
Listing of Duties/Tasks by P. O. Numt r	1
DUTY A MAINTAINING RECORDS 1. Maintain laboratory notebook	1 2 3 4 5 6 7
DUTY B INSTALLING LASER SYSTEMS 8. Install gaseous laser system 9. Install solid state (YAG) laser system	8 10
DUTY C MAINTAINING LASER SYSTEMS 10. Inspect reflecting mirrors and focusing optics	13 14 16 18 20 21 22 23 24 26 28 29 32 33 35 36 37



TABLE OF CONTENTS (Continued)

		Pa	ge
DUTY	С	MAINTAINING LASER SYSTEMS (CONTINUED) 28. Verify lens focal length	39 40
DUTY	D	ANALYZING DOWN LASER SYSTEMS 30. Identify symptoms of problem	41 42 44 46 48 50 52 54
DUTY	E	46. Replace heat exchanger	56 58 60 62 64 66 70 72 74 75
DUTY	F	51. Replace gaseous tube	78 81 84 85 87 90 92 93 94 96 00 02



vii

TABLE OF CONTENTS (Continued)

			Page
DUTY	G	REPAIRING EXCITATION SYSTEM 65. Replace high voltage capacitors	105 107 109 111 112 113 115 117 119 121
DUTY	Н	REPAIRING LOW VOLTAGE POWER SUPPLY 75. Replace capacitor(s)	123 125 127 129
DUTY	I	REPAIRING RF SYSTEM 79. Replace RF cable connector(s)	131 133
DUTY	J	REPAIRING VACUUM SYSTEM 81. Replace vacuum pump	135 137 139 140
DUTY	K	REPAIRING GAS SUPPLY SYSTEM 85. Replace gas flow gauge(s)	142 144 146 148 150
APPENDICES	;		
А В.		Standard Tool Kit Contents	153
		Systems Technician Using	154
C D		Bibliography: Sources of Standards Cross-Reference Table	157 158
E F		State-of-the-Art BibliographyV-TECS Developmental Model	167 169



viii

INTRODUCTION

The Vocational-Technical Education Consortium of States (V-TECS) is a cooperative research and developmental effort among several states with associate membership being held by the Community College of the Air Force; the Department of the Army, Training and Doctrine Command; and the U. S. Naval Education and Training Command.

V-TECS Catalog Description

This V-TECS catalog was developed for the domain area of Laser Systems Technician.

Laser Technician

D.O.T. Code 019.181-010

Laser Systems Technician

D.O.T. Code N/A

A major portion of the catalog (pages 1 through 151) descriptions of the domain area as graphically shown in Figure 1.

On using the information on a respective catalog page, as represented in Figure 1, the following should be noted.

- I. Duties are defined as a major segment of work-related activities for the domain area of the laser systems technician. Duties are comprised of related tasks.
- 2. Tasks are discrete units of work-related activities that constitute logical and necessary activities in the performance of a duty. A task has definite beginning and ending points in accomplishment and generally consists of two or more definite steps in completing.
- 3. Duties and tasks are not necessarily in a sequential order. However, tasks within a duty were written to be highly-related to the respective duty.



ix

PERFORMANCE OBJECTIVE NO: 22

TASK: Inspect cooler fittings

STANDARD: All internal contaminents, leaks, and cross threaded

fittings must be identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage probe Safety glasses

Service report Shorting bar

PERFORMANCE GUIDE:

1. Put on safety glasses.

2. Shut down complete laser system

3. Disconnect main power.

Insert shorting bar.
 Attach high voltage probe.

6. Heasure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.

7. Gain access to fittings.

8. Examine inside of transparent hose at fittings for contaminent build-up.

9. Examine fittings for coolant leaks.

a. Replace fittings if necessary.

10. Examine fittings for cross threading. a. Replace fittings if necessary.

11. Remove shorting bar

12. Connect main power.

13. Remove safety grasses.

Return laser system to service

15. Prepare service report.

SOURCE FOR STANDARD:

- Performance guides are a series of steps arranged in a sequence that when followed would result in the performance and completion of a stated task. It should be noted that the listed performance guides may not be the only sequential steps that could be followed.
- 5. Performance objectives identify the conditions (such as equipment, tools, supplies, and implements) required to complete the task (action required) as well as a standard (criterion) of occupational-related requirements for acceptable completion of the task.



In the search for incumbents, Associated Educational Consultants, Inc., canvassed more than 1641 possible employers of laser and laser systems technicians. Of these, 146 responses were received. However, the majority of these incumbents were classified by their employers as electro-optics technicians. Because of the relative infancy of the profession, the current population of actual laser systems technicians is extremely small. Occupational inventories were sent to the seven (7) employers indicating that they did indeed employ laser and/or laser systems technicians.

Seventeen (17) surveys were returned. Continued efforts to identify other incumbents failed. The total of 17 returned surveys provided a response rate of just over 50% for the surveys distributed for this catalog.

The survey instrument consisted of 11 duties, 86 tasks, and a listing of 109 tools, equipment, and work-aids, all based upon a state-of-the-art review of the domain area and interviews with 16 incumbents. Data were processed on the returned surveys; data were analyzed and task synthesized by a writing team of three (3) laser systems technicians from laser manufacturers and manufacturing establishments employing laser systems technicians. A draft catalog was reviewed by three (3) laser systems technicians from Pennsylvania.

In addition to the performance objectives and performance guides section, the catalog also contains the following:

1. Appendix A, page 153 the contents of the standard tool kit used by laser systems technicians.



хi

- 2. Appendix B, page 154, a listing by percent use by surveyed incumbents those tools, equipment, and work-aids used in the occupation.
- 3. Appendix C, page 157, a bibliography of all sources of standards cited in the catalog.
- 4. Appendix D, page 158, a cross-reference table listing the duties and tasks as they appeared in the survey instrument (occupational inventory); the disposition of duties and tasks within this catalog; and the results of the incumbent responses by number and percent performing.
- 5. Appendix E, page 167, a bibliography of state-of-the-art references identified during the catalog development.
- 6. Appendix F, page 169, a graphic representation of the V-TECS developmental model.

<u>V-TECS</u> Catalog Uses

The intent of this V-TECS catalog is to provide an incumbent based description of duties, tasks, performance objectives, performance guides, and related data in the domain area of Laser Systems Technician. This catalog was compiled for a specific audience, such as instructional materials developers, curriculum developers, educators, researchers, business or professional or industrial applications, or evaluators, for each audience could have wanted a less transferrable outcome. However, due to the emphasis of the catalog being incumbent based, all the above users and many more have a researched based document applicable to their specific needs. Because of the high technology aspect of this



xii

catalog, it is important to read and adhere to the USER'S NOTE at the beginning of this document.

By all means not an all inclusive listing of catalog uses, the following is given as examples of catalog implementation. Generically, as an incumbent based document, the V-TECS catalog within a specified domain area can be applied in the areas of accountability; budget (line items dealing with instruction); articulation (both horizontal and vertical); resources identifications; needs assessment; competency/ performance-based instruction (establishing, monitoring, confirming); counseling; individualized instruction; program profits; program/student evaluation; and student placement/progression.

It must be noted that the V-TECS catalog serves as a resource document for all the uses mentioned above and as such cannot be directly absorbed or adopted as a specified use.

Specifically, components of the catalog can be used as follows.

<u>Duties</u>. The duties are distinct major activities engaged in by incumbents. Duties can be used as (1) a functional organization basis for instructional programs, (2) a basis for assessment (placement and progression), and (3) a basis for terminal objectives.

Tasks. Duties are constituted with highly related work activities called tasks. Tasks can be used as: (1) a functional organization for instructional increments within duties, (2) a basis for instructional assessment (placement and performance), and (3) a basis for planning individualized instruction. Additionally, tasks can serve as part of a basis to certify completus of a program or placement of individuals within a domain area.

xiii



<u>Performance Guides</u>. Activities steps (doing steps) in a sequence leading to the accomplishment of a task are called performance guides. As such, performance guides can serve in (1) establishing enabling instructional objectives, (2) curriculum/instructional materials design, and (3) establishing enabling standards.

Performance Objectives. Performance objectives describe the action, conditions for actions, and standard of acceptability leading to the completing of a task. As such performance objectives can be used (1) to establish terminal objectives for instruction/placement, (2) as a comparison to existing setting for updating, revising, or concurrence, (3) to establish the basis for competency/performance-based efforts, (4) in needs assessment, and (5) goal(s) setting.



xiv

PERFORMANCE OBJECTIVES

AND

PERFORMANCE GUIDES



PERFORMANCE OBJECTIVE NO. 1

TASK: Maintain laboratory notebook

STANDARD: Laboratory notebook must contain all information from experiments, recent tests, repairs, and/or operational notes. Information logged must be dated and initialed

when entered into laboratory notebook.

CONDITIONS FOR PERFORMANCE OF TASK:

Laboratory notebook Notes from tests, observations, repairs, etc.

PERFORMANCE GUIDE:

1. Obtain current data from notes, technical reports, and service reports to be incorporated in laboratory notebook.

2. Log information into notebook according to categories:

- a. Repairs
- b. Tube characteristics
- c. High voltage power supply characteristics
- d. Low voltage power supply characteristics
- e. Model number and make of equipment.
- 3. Date recorded information.
- 4. Initial recorded information.
- 5. Review notebook with supervisor.
- 6. Obtain "witness" signature.
- 7. Review notebook periodically.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 2

TASK: Prepare operational log book

STANDARD: Operational log book must be dated and initialed.

Data must include characteristics of tube, low voltage,

and/or excitation system.

CONDITIONS FOR PERFORMANCE OF TASK:

Operational log book

PERFORMANCE GUIDE:

- Observe operation of system or component of system to be documented.
- 2. Record data which may include:
 - a. Beam diameter
 - b. Beam divergence
 - c. Beam power
 - d. Mode change
 - e. Gas pressure
 - f. Wave length
 - q. Pulse rate
 - h. Pulse width
 - i. High voltage characteristics
 - j. Low voltage characteristics
 - k. Log time (number of hours operated).
- 3. Analyze data.
- 4. Record summary analysis.
- 5. List start-up and shut-down operator.
- 6. Date logged information.
- 7. Initial logged information.
- 8. Submit operational log book for review.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 3

TASK: Prepare shop drawing(s)

STANDARD: Completed shop drawings must contain latest engineering

revisions and must be approved by engineering depart-

ment.

CONDITIONS FOR PERFORMANCE OF TASK:

Copy of latest engineering revisions Shop drawings

PERFORMANCE GUIDE:

1. Obtain drawings of laser system.

2. Acquire copy of latest engineering revisions to laser system.

3. Inspect shop drawings.

Change shop drawing(s) to comply with engineering revisions.

Obtain approval of shop drawing(s) from engineering department.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 4

TASK: Prepare equipment requisition

STANDARD: Equipment requisition must be signed and dated and must

contain all information necessary to fulfill request.

CONDITIONS FOR PERFORMANCE OF TASK:

Requisition Equipment details

PERFORMANCE GUIDE:

1. Obtain blank requisition form.

2. Complete required information as necessary:

a. Exact type and size of equipment needed

b. Serial numbers if applicable

c. Name of project for which equipment is needed

d. Date by which equipment is needed

e. Supplier's name

f. Supplier's address

g. Price of equipment

h. Exact delivery location.

3. Sign requisition form as necessary.

4. Date requisition form.

5. Obtain authorized signature of supervisory personnel.

 Dispatch requisition according to established facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 5

TASK: Prepare service report

STANDARD: Completed service report must be signed and must include: descriptions of work performed; results of

work; list of all parts worked on and repaired; time

spent; and date of repair.

CONDITIONS FOR PERFORMANCE OF TASK:

Parts inventory Service report Service request

PERFORMANCE GUIDE:

- 1. Record date.
- 2. Record laser malfunction and symptoms.
- 3. Note and record all serial numbers of equipment worked on.
- 4. Record time spent in repair and/or maintenance of laser.
- 5. Describe all work performed.
- 6. List all parts used to repair system with part numbers and price.
- 7. Describe result(s) of service to laser system.
- 8. Provide procedure to eliminate recurrence of problems.
- 9. Sign completed service report.
- 10. Submit completed service report to appropriate department according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 6

TASK. Prepare expense report

STANDARD: Completed expense report must be signed and dated.
Report must include totaled amounts of itemized cash
expenses and itemized charged expenses. Receipts must
be attached to report.

CONDITIONS FOR PERFORMANCE OF TASK:

Expense report form Receipts

PERFORMANCE GUIDE:

- 1. Obtain expense report form.
- 2. Fill in name and date.
- 3. Fill in report period dates.
- 4. Fill in customer facility name and address.
- 5. List expenses incurred during specified report period for:
 - a. Mileage for personal vehicle
 - b. Tolls
 - c. Parking
 - d. Plane fare
 - e. Car rental
 - f. Lodging
 - g. Meals
 - h. Telephone
 - Miscellaneous.
- 6. Attach receipts to expense report.
- 7. Indicate on all expenses whether:
 - a. Expense was charged to company (credit cards), or
 - b. Expense was paid in cash.
- 8. Total all charged expenses.
- 9. Total all cash receipts.
- 10. Sign and date expense report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 7

TASK: Update technical manual

Changes in technical manual must be approved by STANDARD:

engineering department. Manual must contain latest changes in laser system; all changes must be dated

and initialed.

CONDITIONS FOR PERFORMANCE OF TASK:

Laser manufacturer's design update Notes on changes Technical manual

PERFORMANCE GUIDE:

 Collect notes on laser system changes.
 Submit proposed changes (per design update) to engineering department prior to making changes.

3. Add changes to manual.

4. Date changes.

5. Initial changes.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 8

TASK: Install daseous laser system

STANDARD: Primary and secondary water lines must be connected and must not leak. Water must flow through laser head within temperature range specified in laser system service manual. Voltage connectors and cables must be tight with no open circuits. Insulation must be intact. Current must run within recommended range according to laser system service manual. Shield gases and gas supply must flow as specified in laser system service manual. Established safety policies and procedures must be followed. Any system damage must be reported to authorized personnel. Laser power output and beam characteristics must meet laser system specifications. Caution signs must be put in place.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Caution signs
Helium neon alignment laser
Laser power meter
Laser safety goggles for
specified wave length
Laser system service manual

Manufacturer's installation manual Operational log book Oscilloscope Safety glasses Safety policies and procedures Thermometer VOM

PERFORMANCE GUIDE:

- 1. Inspect shipping crate(s) for damage.
- 2. Report any damage to authorized personnel.
- Unpack crate(s).
- 4. Verify parts inventory with parts received.
- 5. Read manufacturer's installation manual.
- Place laser system in accordance with laser system specifications.
- 7. Post caution signs.
- 8. Put on safety glasses.
- 9. Level laser head in accordance with manufacturer's installation manual.
- 10. Tie-down laser as required.



PERFORMANCE OBJECTIVE NO. 8

TASK: Install gaseous laser system (Continued)

11. Remove safety glasses.

12. Put on laser safety goggles.

13. Align laser internally.

14. Level and tie-down work station as required.

a. Turn on helium neon alignment laser.

- b. Align helium neon laser coincident to laser beam.
- c. Place work station in line with helium neon beam. Note: Beam must hit centers of entry and exit holes in enclosure.
- d. Level jacks at all corners of work station.
- e. Install cover at exit hole if necessary. CAUTION: EXIT HOLE MUST BE CLOSED AT ALL TIMES EXCEPT FOR ALIGNMENT OR INSTALLATION PROCEDURES.

f. Align external optics.

- 15. Connect shield gas(es) as required in accordance with manufacturer's installation instructions.
- 16. Connect input and output secondary water lines as required.
- 17. Connect input and output primary water lines as required.
- 18. Connect gas supply hose(s) as required in accordance with manufacturer's installation instructions.

 CAUTION: DO NOT OPEN GAS VALVE UNTIL AUTHORIZED TO DO SO.
- 19. Connect electrical connections in accordance with local electrical codes and regulations and manufacturer's installation instructions.
- 20. Tighten all connections.
- 21. Remove obstacles from beam path.
- 22. Place beam stop at end of beam path.
- 23. Review safety policies and procedures.
- 24. Energize laser.
- 25. Note that laser tube discharges.
 - Troubleshoot beam generation system if tube does not discharge.
- 26. Set current to recommend running range according to laser system specifications.
- 27. Check mode.
 - a. Adjust internal optics if necessary.
- 28. Measure output power.
- 29. Record reading in operational log book.
- 30. Measure laser stability.
- 31. Record reading in operational log book.
- 32. Remove laser safety goggles.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 9

TASK: Install solid state (YAG) laser system

STANDARD: Primary and secondary water lines must be connected and must not leak. Water must flow through laser head within temperature range specified in laser system service manual. Voltage connectors and cables must be tight and unbroken. Current must run within recommended range according to laser system system specifications. Laser power output and beam characteristics must meet laser system specifications. Caution signs must be in place. Any damage to system must be reported to authorized personnel.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Black light
Caution signs
Distilled water
Laser power meter
Laser pulse detector
Laser Safety goggles for
specified wave length

Laser system service manual
Manufacturer's installation
manual
Operational log book
Oscilloscope
Phosphor screen
Safety policies and procedures
Thermometer
VOM

PERFORMANCE GUIDE:

- 1. Inspect shipping crate for damage...
- 2. Report any damage to authorized personnel.
- 3. Unpack laser power supply and cooler from shipping crate.
- 4. Verify parts inventory with parts received.
- 5. Read manufacturer's installation manual.
- 6. Place laser system in accordance with laser system specifications.
- 7. Post caution signs.
- 8. Test water temperature to see that it is in specified range indicated in laser system service manual.
 - a. Proceed with step #9 if water temperature is in recommended range.
 - b. Increase flow of water if temperature is too high, or
 - c. Arrange for external chilling system for water intake.
- 9. Connect input and output secondary water lines to heat exchanger.



PERFORMANCE OBJECTIVE NO. 9

TASK: Install solid state (YAG) laser system (Continued)

- Connect input and output primary (closed loop) water lines to laser head.
- 11. Connect laser high voltage connector from power supply to laser head.
- 12. Tighten connector securely.
- 13. Connect interlock cable from RF driver to laser head.
- 14. Connect RF BNC cable from RF driver to laser head.
- 15. Connect input voltage power cable to laser power supply.
- Inspect system for any loose or broken connections before applying power.
 - a. Tighten loose connections if necessary.
 - Replace broken connections if necessary.
 CAUTION: DO NOT APPLY POWER UNTIL AUTHORIZED TO DO SO.
- 17. Fill cooler reservoir tank with distilled water.
- 18. Plug voltage input cable into wall source.
- 19. Turn on cooler switch.
- 20. Note that water is circulating through laser head.
 - a. Add more water if low level light is lit.
- 21. Review safety policies and procedures.
- 22. Remove obstacles from beam path.
- 23. Place beam stop at end of beam path.
- 24. Put on laser safety goggles.
- 25. Energize laser.
- 26. Note that lamp ignites.
 - a. Troubleshoot beam generation system if lamp does not ignite.
- 27. Set current to recommended running range according to laser system service manual.
- 28. Place black light and phosphor screen in front of beam expander.
- 29. Observe that laser is operating in specified mode.
 - a. Troubleshoo+ beam generation system if laser is not operating in specified mode.
- 30. Check mode.
 - a. Adjust internal optics if necessary.
- 31. Measure output power.
- 32. Record reading in operational log book.
- 33. Measure laser stability.



PERFORMANCE OBJECTIVE NO. 9

TASK: Install solid state (YAG) laser system (Continued)

34. Record reading in operational log book. 35. Remove laser safety goggles.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 10

TASK: Inspect reflecting mirrors and focusing optics

STANDARD: All burns, discolorations, dust, film, chips, cracks,

pits, or scratches must be identified. Reinstalled

optics must be aligned.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Instructions for cleaning optics Lens cleaner Lens tissue Service report

Laser system service manual

PERFORMANCE GUIDE:

- 1. Shut down laser system.
- 2. Disconnect main power.
- 3. Wash hands.
- 4. Review manufacturer's specifications for position and access to optics.
- 5. Gain access to optic system.
- 6. Identify surface contamination:
 - a. Burned coatings
 - b. Discolorations
 - c. Dust
 - d. Film
 - e. Chips/cracks/pits
 - f. Scratches
- 7. Clean or replace optics.
- 8. Reinstall optics in system.
- 9. Realign optics.
- 10. Connect main power.
- 11. Return laser system to service.
- 12. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 11

TASK: Clean optics

STANDARD: Optics must be aligned and must be free of any

contaminants. Manufacturer's instructions must be followed for specific types of optics being cleaned.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Lens paper

Duster Manufacturer's instructions for

Isopropyl alcohol specific optics
Laser system service manual Service report

PERFORMANCE GUIDE:

- 1. Review laser system service manual for access to optics.
- 2. Review manufacturer's instructions for cleaning specific optics.
- 3. Wash hands.
- 4. Remove front cap.
- 5. Remove set screws from rear cap.
- 6. Remove rear cap.

For stationary mirrors:

- a. Blow dust off mirror.
- b. Saturate lens paper with isopropyl alcohol.
- c. Wipe mirrors according to manufacturer's instructions.

For removable mirrors:

- a. Remove mirror mount(s).
- b. Blow dust off mirror.
- c. Saturate lens paper with isopropyl alcohol.
- d. Wipe mirrors according to manufacturer's instructions.
- e. Return mirror mount(s) to laser tube.
- f. Replace mirror mount(s).
- g. Align laser optics.
- 7. Replace front cap on laser housing.
- 8. Replace rear cap on housing.
- 9. Tighten set screws on rear cap.



PERFORMANCE OBJECTIVE NG. 11

TASK: Clean optics (Continued)

- 10. Test laser operation.
- 11. Return laser system to service.12. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 12

TASK: Verify Q-switch in YAG laser system

STANDARD: Q-switch must pass beam in CW (continuous wave)

position and must block beam in external mode. Laser Q-switch power must be in conformance with laser system

specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Black light
Laser safety goggles for
specified wave length
Laser system service manual
Lens tissue

Methyl alcohol Phosphor screen Q-switch RF power meter Service report

PERFORMANCE GUIDE:

- Review laser system service manual.
- 2. Put on laser safety goggles.
- 3. Shut down laser system.
- 4. Disconnect main power.
- 5. Disconnect RF input cable from Q-switch.
- 6. Close shutter.
- 7. Remove Q-switch assembly from laser rail.
- Inspect both optical surfaces of Q-switch quartz block for burns or scratches.
 - a. Replace O-switch if burns or scratches are observed.
- Inspect both optical surfaces of Q-switch quartz block for dirt or film.
 - a. Clean optical surfaces if dirt or film is observed.
- 10. Replace Q-switch assembly onto laser rail.
- 11. Secure Q-switch.
- 12. Place black light and phosphor screen in front of output beam expander.
- 13. Energize laser.
- 14. Open shutter.
- 15. Place RF mode switch in CW (continuous wave) position. Note: Beam will appear on screen.
- 16. Place RF mode switch in external position.



PERFORMANCE OBJECTIVE NO. 12

TASK: Verify Q-switch in YAG laser system (Continued)

- 17. Observe screen for disappearance of beam.
 - a. Proceed with step #18 if beam has disappeared.
 - b. Proceed as follows if beam has not disappeared.
 - Test RF power level on Q-switch.
 - (2) Adjust bragg angle.
 - (3) Replace Q-switch if neither (1) or (2) results in beam disappearance.
- 18. Close shutter.
- 19. Remove black light and phosphor screen.
- 20. Remove laser safety goggles.
- 21. Return laser system to service.
- 22. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 13

TASK: Verify polarizer in YAG laser system

STANDARD: TEMOO (transverse electromagnetic mode) output must be

stable with minimum insertion loss. Optical plates

must be free of dirt, scratches, and film.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Black light
Laser safet, goggles for
specified wave length

Polarizer Phosphor screen Service report

PERFORMANCE GUIDE:

- Put on laser safety goggles.
- 2. Energize laser.
- 3. Set laser to normal operating current in TEM_{00} (transverse electromagnetic mode).
- 4. Close shutter.
- 5. Place black light and phosphor screen in front of output beam expander.
- 6. Remove cover on polarizer assembly.
- 7. Remove polarizer plate block from polarizer assembly.
- 8. Inspect both front and back optical plates for:
 - a. Burns
 - b. Scratches
 - c. Dirt
 - d. Film.
- 9. Replace defective polarizer plate(s) if necessary.
- 10. Open shutter.
- 11. Peak laser rear mirror for best round multimode beam structure.
- 12. Insert polarizer plate block into polarizer assembly. Note: Beam mode structure on phosphor screen will be displayed as a cross image.
- 13. Peak rear mirror to sharpen cross image.
- 14. Close shutter.
- 15. Shut down laser system.
- 16. Remove laser safety goggles.



PERFORMANCE OBJECTIVE NO. 13

TASK: Verify polarizer in YAG laser system (Continued)

- 17. Remove black light and phosphor screen from laser output.
- 18. Return laser system to service.
- 19. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 14

TASK: Test power/energy output at source

STANDARD: Power/energy output at source not in conformance with

laser system specifications must be identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Laser safety goggles for specified wave length Laser system service manual

Operational log book Power meter/energy meter Service report

PERFORMANCE GUIDE:

Put on laser safety goggles.

2. Align power meter/energy meter with beam path.

3. Check laser system service manual for recommended power output.

4. Set power meter range.

5. Zero power meter.

6. Energize laser.

7. Record power reading/energy reading in operational log book.

8. Determine if power output is within recommended range.

a. Proceed to step #9 if power output is in conformance with laser system service manual.

b. Troubleshoot beam generation system if power output is not within specified range.

9. Shut down laser system.

10. Remove power meter from optical path.

11. Remove laser safety goggles,

12. Return laser system to service.

13. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 15

TASK: Verify thermal switch operation

STANDARD: Thermal switches not activating at temperature

specified in laser system specifications must be identi-

fied and replaced.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Heat gun
High voltage probe
Laser safety goggles for
specified wave length

Laser system service manual Service report Shorting bar Thermocouple meter

PERFORMANCE GUIDE:

- 1. Put on laser safety goggles.
- Energize laser system. CAUTION: DO NOT TURN ON HIGH VOLTAGE POWER SUPPLY.
- 3. Insert shorting bar.
- 4. Attach high voltage probe.
- 5. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 6. Gain access to thermal switch.
- 7. Attach thermocouple meter to thermal switch.
- 8. Turn on heat gun and direct air to temperature switch.
- 9. Observe thermocouple reading when system thermal interlock activates.
- 10. Compare thermocouple temperature reading to laser system specifications.
 - a. Proceed to step #11 if readings are in conformance with laser system specifications.
 - b. Proceed as follows if readings are not in conformance until problem has been identified and corrected.
 - (1) Replace thermal switch.
 - (2) Troubleshoot temperature control system.
- Remove shorting bar.
- 12. Remove laser safety goggles.
- 13. Return laser system to service.
- 14. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 16

TASK: Test RF power on Q-switch

STANDARD: RF forward and reverse power not in conformance with

laser system specifications and/or Q-switch not holding

off output beam must be identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit RF power meter
BNC cable Safety glasses
Laser system service manual Service report
Operational log book

PERFORMANCE GUIDE:

- 1. Put on safety glasses.
- 2. Shut down RF driver.
- 3. Disconnect BNC cable from RF output.
- 4. Connect RF power meter between RF output and Q-switch.
- 5. Turn on RF driver power.
- 6. Set meter element to forward direction.
- 7. Record meter reading in operational log book.
- 8. Review laser system service manual for recommended setting.
- 9. Adjust RF power control if necessary.
 - a. Replace RF driver if power cannot be adjusted to recommended setting.
- 10. Set meter element to reverse direction.
- 11. Record reflective power reading.
 Note: Reflective power must conform to laser system specifications.
- 12. Determine if reflective power is excessive.
 - a. Replace Q-switch, or
 - b. Replace RF driver to achieve impedance match.
- 13. Remove safety glasses.
- 14. Return laser system to service.
- 15. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 17

TASK: Change water filter

STANDARD: Water filter assembly must be free of leaks. Cooler

flow rate must be in conformance with laser system

specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit 0-ring

Filter Safety glasses Laser system service manual Service report

PERFORMANCE GUIDE:

1. Put on safety glasses.

2. Shut down laser power supply.

3. Shut down water pump.

- 4. Remove water filter canister retainer nut.
- 5. Drop filter canister from top assembly.
- 6. Remove old filter insert from canister.
- 7. Crop new filter insert into canister.
- 8. Insert new O-ring.
- 9. Seat canister up into top assembly.
- 10. Tighten retainer nut.
- 11. Add water to cooler reservoir if necessary.
- 12. Adjust water flow to recommended rate as specified in laser system service manual.
- 13. Turn cooler pump on.
- 14. Check for leaks.
- 15. Check flow rate.
- 16. Remove safety glasses.
- 17. Return laser system to service.
- 18. Prepare service report.
- 19. Dispose of defective water filter according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 18

TASK: Change deionizer cartridge holder

STANDARD: Deionizer cartridge holder must not leak coolant.

Coolant level must be in conformance with laser system

Safety glasses

specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Coolant Deionizer cartridge

Service report Shorting bar MOV High voltage probe

Laser system service manual

- Put on safety glasses.
- 2. Shut down complete laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to cartridge holder.
- 8. Close inlet and outlet coolant flow valves.
- 9. Disconnect deionizer cartridge holder housing.
- 10. Remove old cartridge from housing.
- 11. Clean out housing with clean rag.
- 12. Install new cartridge in housing.
- 13. Connect cartridge holder housing.
- 14. Open inlet and outlet coolant valves.
- 15. Clean up any coolant spillage.
- 16 Connect main power.
- 17. Energize laser temperature control system.
- 18. Check cartridge holder for leaks.
 - a. Tighten cartridge in housing if necessary.
- Replenish lost coolant in cooler reservoir to recommended "evel specified in laser system service manual.



PERFORMANCE OBJECTIVE NO. 18

TASK: Change deionizer cartridge holder (Continued)

- 20. Remove shorting bar.
- 21. Remove safety glasses.
- 22. Return laser system to service.
- 23. Prepare service report.
- 24. Dispose of defective deionizer cartridge according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 19

TASK: Adjust power supply output

STANDARD: Current at power supply output must be in conformance

with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage probe Laser safety goggles for specified wave length

Laser system service manual Service report Shorting bar VOM

- 1. Put on laser safety goggles.
- 2. Shut down complete laser system.
- 3. Disconnect main power.
- 4. Remove power supply cover.
- 5. Insert shorting bar.
- 6. Attach high voltage probe.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Connect VOM in series with laser tube.
- 8. Set VOM range.
- 9. Zero meter.
- 10. Check laser system service manual for specified power output.
- 11. Remove shorting bar.
- 12. Connect main power.
- 13. Energize laser system.
- 14. Note meter reading.
- 15. Adjust current POT (potentiometer) to laser system specifications.
- 16. Shut down complete laser system.
- 17. Disconnect main power.
- 18. Disconnect VOM.
- 19. Replace and secure power supply cover.



PERFORMANCE OBJECTIVE NO. 19

TASK: Adjust power supply output (Continued)

- 20. Remove laser safety goggles.
- Return laser system to service.
 Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 20

TASK: Align complete beam delivery path

STANDARD: Laser beam must be centered to each beam bender mirror.

Laser beam must be centered to focusing lens Power reading at work surface must be in conformance with

laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit

Adjustable jack stands

Black light

Cross hair

End cap pin holes

Helium neon alignment laser

Laser power meter

Laser safety goggles for

specified wave length

Laser system service manual

Phosphor screen

Service report

PERFORMANCE GUIDE:

- Put on laser safety goggles.
- 2. Remove work surface focusing lens and guard shield.
- 3. Center beam to first beam bender mirror.
- 4. Center beam to next beam bender by adjusting previous beam bender mirror adjustments.
- 5. Continue until all beam bender mirrors are adjusted.
- 6. Screw cross hair in focusing lens mount.
- 7. Center beam in cross hair using previous beam bender mirror mount adjustments.
- 8. Remove cross hairs.
- 9. Align power meter with beam path.
- 10. Zero meter.
- 11. Set meter for output power range specified in laser system service manual.
- 12. Energize laser.
- 13. Adjust laser power output to laser system specifications.
- 14. Remove power meter.
- 15. Replace work surface focusing lens and guard shield.
- 16. Remove laser safety goggles.
- 17. Return laser system to service.
- 18. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 21

TASK: Align laser cavity optics

STANDARD: Laser must perform in conformance with laser system

specifications. Laser beam must be centera' to focusing lens. Power reading at work surface must be in conform-

ance with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Adjustable jack stands
Black light
Cross hair
End cap pin holes
Expander lens
Helium neon alignment laser

Laser power meter
Laser safety goggles for
specified wave length
Laser system specifications
Phosphor screen
Service report

- 1. Put on laser safety glasses.
- 2. Shut down laser power supply.
- 3. Shut down power to cooler.
- 4. Install one end cap pin hole on both left and right mirror mounts.
- 5. Position helium neon laser 10 inches in front of front mirror mount.
- 6. Position phosphor screen 10 inches in front of front mirror mount.
- 7. Remove Q-switch from rail on YAG lasers.
- 8. Adjust helium neon laser in both horizontal and vertical axis until red beam shines through both pin holes and appears on screen.
- 9. Loosen lock clamps on both left and right mirror adjustments.
- 10. Remove pin holes from mirror mounts.
- Locate group of 4 reflections in various positions shining back on neon laser front plate.
 Note: Fundamental red output beam is your center reference beam.



PERFORMANCE OBJECTIVE NO. 21

TASK: Align laser cavity optics (Continued)

- 12. Identify 4 reflections as follows:
 - a. Rear mirror
 - b. Front mirror
 - c. Rear face of crystal rod
 - d. Front face of crystal rod.
- 13. Rotate crystal rod and/or adjust laser pot assembly so front and rear rod reflections superimpose themselves on fundamental axis beam.
- 14. Adjust rear mirror reflection axis at least 3 or 4 turns off axis so laser will not emit beam.
- 15. Energize laser and cooler to ignite lamp.
- 16. Adjust pump current up and down from 15 amps to 35 amps and observe that:
 - a. Both rod reflections remain centered on fundamental axis. Proceed to b. if reflections are not centered.
 - b. Rotate rod adjusting pot assembly horizontally or slightly adjust red laser position until condition ais satisfied.
- 17. Lock rod and pot assembly in position.

 Note: Do not move neon laser anymore, as this is the reference axis.
- 18. Adjust front mirror so its reflection is centered on red beam reference axis.
- 19. Lock down mirror adjustments.
- 20. Place black light and phosphor screen in front of laser.
- 21. Turn black light on to illuminate phosphor screen.
- 22. Install expander lens on front mirror mount.
- 23. Adjust pump current to running current setting recommended in laser system specifications.
- 24. Adjust rear mirror reflection to superimpose on reference axis.

 Note: On YAG lasers, 1.06a YAG beam should appear on phosphor screen with red beam in center.
- 25. Remove black light and screen from front of laser.
- 26. Measure output power.
- 27. Peak to maximum power with rear mirror adjustment.
- 28. Lock rear mirror.
- 29. Reduce pump current below threshold.
- 30. Reinstall Q-switch on YAG lasers.
- 31. Center its reflections on reference axis.
- 32. Lock down.



PERFORMANCE OBJECTIVE NO.

TASK: Align laser cavity optics (Continued)

- 33. Install aperture for specified mode structure.
- 34. Remove laser safety goggles.35. Set power supply to running current.
- 36. Return laser system to service.
- 37. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO: 22

TASK: Inspect cooler fittings

STANDARD: All internal contaminents, leaks, and cross threaded

fittings must be identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage probe Safety glasses Service report Shorting bar

PERFORMANCE GUIDE:

1. Put on safety glasses.

- 2. Shut down complete loser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to fittings.
- 8. Examine inside of transparent hose at fittings for contaminent build-up.
- 9. Examine fittings for coolant leaks.
 - a. Replace fittings if necessary.
- 10. Examine fittings for cross threading.
 - a. Replace fittings if necessary.
- 11. Remove shorting bar.
- 12. Connect main power.
- 13. Remove safety glasses.
- 14. Return laser system to service.
- 15 Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 23

TASK: Inspect air circulating filter(s)

STANDARD: Air circulating filters that are dirty, oily, or worn must be identified. Filters must be installed in con-

formance with laser system specifications and replaced filters must be of the same size and type as recommended

in laser system service manual.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses High voltage probe Service report Laser system service manual Shorting bar Light source

- Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Locate air filter(s).
- 8. Remove filter(s) from system.
- 9. Hold filter up to light source.
- 10. Examine filter for:
 - a. Build-up of dirt and/or oil
 - b. Signs of filter deterioration and/or wear.
- 11. Clean or replace filter as necessary.
- 12. Repeat steps #9 and #10 for each air circulating filter within laser system.
- 13. Reinstall air filter(s).
- 14. Remove shorting bar.
- 15. Connect main power.



PERFORMANCE OBJECTIVE NO. 23

TASK: Inspect air circulating filter(s) (Continued)

- Remove safety glasses.
 Return laser system to service.
 Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 24

TASK: Clean air circulating filter(s)

STANDARD: Air circulating filters must be free of visible dirt and

oil and must be installed in conformance with laser

system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit

Filter coating

High voltage probe
Hot air gun
Laser system service manual
Safety glasses

Service report
Shorting bar
Soap
Sink
Water

PERFORMANCE GUIDE:

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voitage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Locate air filter(s).
- δ Remove filter(s) from system.
- 9 Place filter(s) in sink.
- 10. Wash filter(s) with mild soap and water.
- Rinse clean filter(s) with tap water.
- 12. Dry filter(s) with hot air gun.
- 13. Coat filter(s) with filter coating, according to laser system specifications.
- i4. Reinstall air filter(s) to system.
- 15. Remove shorting bar.
- 16. Connect main power.
- 17. Remove safety glasses.
- 18. Return laser system to service.
- 19. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 25

TASK: Replace air circulating filter(s)

STANDARD: Air circulating filter(s) must be replaced with filter(s)

recommended in laser system service manual.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Air circulating filter(s)
Service report
High voltage probe
Laser system specifications
Safety glasses
Service report
Shorting bar

PERFORMANCE GUIDE:

- Review laser system specifications for type and size of replacement filter recommended.
- 2. Put on safety glasses.
- 3. Shut down laser system.
- 4. Disconnect main power.
- 5. Insert shorting bar.
- 6. Attach high voltage probe.
- 7. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 8. Locate air filter(s).
- 9. Remove filter(s) from system.
- 10. Discard used filter(s).
- 11. Install new filter(s) in system.
- 12. Remove shorting bar.
- 13. Connect main power.
- 14. Remove safety glasses.
- 15. Return laser system to service.
- 16 Prepare Service report.
- 17. Dispose of defective filter(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 26

TASK: Measure power/energy output at work surface

STANDARD: Measured power/energy output not in conformance with

laser system specifications must be identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Laser safety goggles for
specified wave length
Laser system service manual

Oscilliscope Power meter/energy meter Pulse detector Service report

PERFORMANCE GUIDE:

- 1. Put on laser safety goggles.
- 2. Remove work surface focusing lens and shield.
- 3. Align power meter/energy meter with beam path.
- 4. Zero meter.
- 5. Set meter for output power range.
- 6. Energize laser.
- 7. Note power reading/energy reading.
- 8. Compare reading to laser system specifications:
 - a. Proceed to step #9 if power output is within laser system specifications.
 - b. Troubleshoot beam generation system if power output is not within laser system specifications.
- 9. Shut down laser.
- 10. Remove power meter.
- 11. Replace focus lens and shield.
- 12. Remove laser safety goggles.
- 13 Return laser system to service.
- 14. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 27

TASK: Verify safety interlock system operation

STANDARD: Laser power supply must shut down when an interlocked

cover is removed.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Interlock system schematic Laser safety goggles for specified wave length

Laser system service manual Service report MOV

PERFORMANCE GUIDE:

- Review interlock system schematic.
- 2. Put on laser safety goggles.
- Energize laser system.
- 4. Set power to recommended operating current according to laser system specifications.
- Remove interlocked cover from laser to initiate interlock operation.
- Determine if laser power supply has automatically shut down.
 - Proceed as follows if laser power supply has not shut down:
 - (1) Check interlock switch with YOM.
 - (2) Check wiring to switch.(3) Check interlock relay.

 - (4) Check control electronics to relay.
 - (5) Replace defective component(s).
- 7. Replace interlocked cover.
- 8. Determine if power supply comes on and beam is restored.
 - Repeat step #6 if not in conformance with laser system specifications.
- 9. Repeat steps #5-8 for all interlock devices.
- 10. Remove laser safety goggles.
- 11. Return laser system to service.
- 12. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 28

TASK: Verify lens focal length

STANDARD: Lens focal length must correspond to manufacturer's

stamped distance on focusing lens.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Focusing lens guard shield
Laser safety goggles for
specified wave length

Measurement medium
(thermoflax paper, etc.)
Measuring scale
Service report

PERFORMANCE GUIDE:

1. Put on laser safety goggles.

Remove focusing lens guard shield.

 Measure distance from focus lens to work surface with measuring scale.

Note: Be careful not to touch optic surface.

- 4. Place measurement medium on work surface table under focusing lens.
- 5. Adjust laser for low power output.
- 6. Energize laser briefly to get focusing lens spot size on measurement medium.
- 7. Jog work table over to new section of measurement medium.
- 8. Adjust focusing fixture up 1/4 inch.
- 9. Energize laser briefly to burn laser focusing lens spot size.
- 10. Jog work table again over to new section of measurement medium.
- 11. Move focusing lens fixture down 1/2 inch.
- 12. Energize laser briefly to burn spot size.
- 13. Compare all spot sizes on measurement medium.
- 14. Determine if smallest spot size corresponds to stamped distance on focusing lens.
 - a. Replace focusing lens if focal length does not correspond to specified focal length.
- 15. Remove laser safety goggles.
- 16. Return laser system to service.
- 17. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 29

TASK: Verify repetition rate

STANDARD: Repetition rate must be set according to laser system

specification for particular application.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses Laser system specifications Service report Oscilloscope/frequency counter

PERFORMANCE GUIDE:

1. Put on safety glasses.

Energize laser system.
 CAUTION: LEAVE HIGH VOLTAGE POWER SUPPLY OFF.

3. Gain access to system pulse generator.

- 4. Connect oscilloscope/frequency counter to output of pulse generator.
- 5. Activate pulse generator.
- Adjust pulse generator to laser system specifications using oscilloscope/frequency counter if not within specification.
- Remove safety glasses.
- 8. Return laser system to service.
- 9. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 30

TASK: Identify symptoms of problem

STANDARD: Problem must be localized to specific inoperative

system within total laser system. Laser operator must be questioned on laser performance and maintenance

records must be reviewed.

CONDITIONS FOR PERFORMANCE OF TASK:

Laser operator Maintenance records Operational log book

PERFORMANCE GUIDE:

- Review maintenance records and operational log book for laser system.
- 2. Discuss maintenance service of laser with maintenance technician if necessary.
- 3. Discuss problem with laser operator.
- 4. Ask laser operator the following questions:
 - a. Is the lamp igniting?
 - b. Does the lamp remain lit?
 - c. Is the cooler functioning?
 - d. Is the RF functioning?
- 5. Localize problem to general area of concern:
 - a. Beam generation system
 - b. Temperature control system
 - c. Excitation system
 - d Low voltage power supply
 - e Rf system
 - f. Vacuum system
 - g. Gas supply system.
- 6. Troubleshoot area where concern is focused.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 31

TASK: Troubleshoot temperature control system

STANDARD: Temperature control system not in accordance with laser system specifications must be identified. Fault indicator lights must be operative but must not be indicating malfunction of system.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Laser system service manual Safety glasses Service report
Thermometer/thermocouple
meter

- 1. Review laser system service manual.
- 2. Put on safety glasses,
- 3. Energize laser system.
 CAUTION: DO NOT ACTIVATE HIGH VOLTAGE.
- 4. Check temperature control panel lights for defects.
 - a. Replace defective bulb(s).
 - b. Repair other defect(s).
- Adjust panel to laser system specifications.
- 6. Check each fault indicated by corresponding panel light as follows, and repair or adjust until problem has been corrected. No coolant flow indicated
 - (a) Check coolant pump.
 - (b) Examine wiring.
 - (c) Check fuses.
 - (d) Verify circuit breaker operation.
 - (e) Check coolant fluid level.
 - (f) Verify operation of flow switch.
 - (g) Verify operation of temperature control switch.
 - Over temperature
 - (a) Check water temperature.
 - (b) Check level of cooler refrigerant.
 - (c) Verify operation of coolant shut-off.
 - (d) Verify operation of compressor.
 - (e) Clean secondary coolant filter.
 - (f) Verify operation of temperature indicator switch.



PERFORMANCE OBJECTIVE NO. 31

TASK: Troubleshoot temperature control system (Continued)

Low Coolant Flow

- (a) Verify operation of flow indicator.
- (b) Clear coolant line of restriction(s).(c) Clean secondary coolant filter.
- 7. Determine that all fault indicator panel lights are off.
- 8. Remove safety glasses.
- 9. Return laser system to service.
- 10. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO.

TASK: Troubleshoot beam generation system

STANDARD: Laser power output, threshold current, RF power and

laser stability must be in conformance with laser

system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Laser power meter Laser safety goggles for specified wave length Laser system service manual

Operational log book Oscilloscope Pulse detector RF meter Service report

- 1. Determine required power output range from laser system specifications.
- 2. Insert laser power meter in beam path.
- 3. Put on laser safety goggles.
- 4. Energize laser.
- 5. Measure laser output.
- 6. Record reading in operational log book.
- 7. Measure laser threshold current.
- 8. Record reading in operational log book.
- 9. Determine if laser output power and threshold current are in conformance with laser system specifications.
 - a. Proceed to step #10 if readings are in conformance with specifications.
 - Proceed through steps below until problem has been identified and corrected if reading is not in conformance with specifications.
 - (1) Shut down laser power supply.
 - (2) Inspect focusing optics.
 - (a) Clean optics.
 - (3) Align optics.
 - (4) Verify Q-switch in YAG laser system.
 - (5) Verify polarizer in YAG laser system.
 (6) Replace lamp jacket if necessary.
 (7) Replace flashlamp if necessary

 - Replace crystal rod if necessary (8)
 - (9) Replace gold cavity if necessary.



PERFORMANCE OBJECTIVE NO. 32

TASK: Troubleshoot beam generation system (Continued)

- (10) Replace gaseous tube if necessary.
- (11) Clean or replace mirror(s).
- (12) Replace mirror mount if necessary.
- (13) Verify peak pulse power.
- (14) Verify frequency of pulse train.
- 10. Measure RF power.
- 11. Record reading in operational log book.
- 12. Determine if RF power is in conformance with laser system specifications.
 - a. Proceed to step #13 if reading is in conformance with specifications.
 - b. Proceed through steps below until problem has been identified and corrected if reading is not in conformance with specifications:
 - (1) Replace cable.
 - (2) Replace controller box.
 - (3) Repair low voltage power supply.
- 13. Measure laser stability with pulse detector and oscilloscope.
- 14. Determine if stability is within laser system's specified range.
 - a. Proceed to step #15 if stability is within specified range.
 - b. Proceed through steps below until problem has been identified and corrected.
 - (1) Check AC ripple percentage on laser supply.
 - (2) Check lamp cooler water for air bubbles.
 - (3) Check laser alignment.
 - (a) Realign if necessary.
 - (A) Check for a r leaks in primary lines.
- 15 Remove laser safety gogyles.
- 16 Return laser system to service.
- 17. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 33

TASK: Troubleshoot excitation system

STANDARD: All defective excitation system components must be

identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
High voitage probe
Laser system service manual
Oscilloscope
Safety glasses
Service report
Shorting bar
YOM

- Review laser system service manual for recommended power readings.
- 2. Put on safety glasses.
- Connect high voltage probe with oscilloscope to output of high voltage power supply.
- Connect high voltage power supply.
- Turn on high voltage power supply.
- 6. Measure output voltage.
- Confirm power supply failure.
- 8. Turn off power supply.
- 9. Discharge power supply.
- 10. Disconnect power supply.
- 11. Insert shorting bar.
- 12. Attach high voltage probe.
- 13. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 14 Remove screws from power supply cover.
- 15. Remove cover from power supply,
- 16. Remove power supply from extrusion.
- 17. Set VOM at recommended range.
- 18. Zero VOM.
- 19. Measure excitation system components proceeding through steps #20-28 until problem has been identified and corrected.
- 20 Measure high voltage diode(s) resistances.
 - a Replace defective diode(s).



PERFORMANCE OBJECTIVE NO. 33

TASK: Troubleshoot excitation system (Continued)

- 21. Measure high voltage capacitors.
 - a. Replace defective capacitors.
- 22. Test resistors.
 - a. Replace defective resistors.
- 23. Test SCR (silicon control rectifier).
 - a. Replace defective SCR.
- 24. Ohm high voltage cables.
 - a. Replace defective cable(s).
- 25. Ohm fuses.
 - a. Replace defective fuse(s).
- 26. Ohm three-phase contactor.
 - a. Replace defective three-phase contactor.
- 27. Ohm high voltage dump contactor.
 - a. Replace defective dump contactor.
- 28. Inspect boards.
- 29. Ohm traces for continuity.
 - a. Repair broken traces.
 - b. Replace defective boards.
- Return power supply to extrusion.
- 31. Replace and secure cover on power supply.
- 32. Remove shorting bar.
- 33. Connect main power.
- 34. Energize laser.
- 35. Confirm excitation system operation.
 - a. Troubleshoot low voltage power supply if excitation system is not operating according to laser system specifications.
 - b. Return to manufacturer for repair if steps #1-34 do not correct problem.
- 36. Remove safety glasses.
- 37. Return laser system service if applicable.
- 38. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 34

TASK: Troubleshoot low voltage power supply

STANDARD: All defective low voltage power supply components

must be identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
High voltage probe
Laser safety goggles for
specified wave length
Laser system service manual
Safety glasses

Schematic of low voltage circuits Service report Shorting bar VOM

- 1. Review schematic of low voltage circuits and laser system service manual for recommended power readings.
- 2. Put on safety glasses.
- 3. Connect VOM to low voltage power supply output.
- 4. Connect main power.
- 5. Energize laser.
- 6. Measure output voltage.
- 7. Confirm power supply failure.
- 8. Shut down laser system.
- 9. Disconnect main power.
- 10. Insert shorting bar.
- 11. Attach high voltage probe.
- 12. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 13. Remove screws from power supply cover.
- 14. Remove cover from power supply.
- Remove low voltage power supply from extrusion.
- 16. Set VOM range at recommended setting.
- 17. Zero VOM.
- 18. Measure low voltage components proceeding through steps #19-29 until problem has been identified and corrected.
- 19. Measure fuse resistance.
 - a. Replace defective fuse.



PERFORMANCE OBJECTIVE NO. 34

TASK: Troubleshoot low voltage power supply (Continued)

- 20. Measure transformer resistance.
 - a. Replace defective transformer.
- 21. Measure resistance of diode(s).
 - a. Replace defective diode(s).
- 22. Measure resistance of resistors.
 - a. Replace defective resistors.
- 23. Measure capacitors.
 - a. Replace defective capacitors.
- 24. Reset VOM range at recommended setting.
- 25. Remove shorting bar.
- 26. Connect main power.
- 27. Energize laser.
- 28. Measure voltage at output of current regulator.
 - a. Replace defective current regulator.
- 29. Confirm low voltage power supply operation.
 - a. Replace low voltage power supply if power supply is not operating according to laser system specifications.
- 30. Return power supply to extrusion.
- 31. Replace and secure cover on power supply.
- 32. Confirm low voltage power operation.
 - a. Troubleshoot excitation system if necessary.
- 33. Remove safety glasses.
- 34. Return laser system to service.
- 35. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 35

TASK: Troubleshoot RF system

STANDARD: Specific problems causing laser beam not holding off in external mode and YAG laser not Q-switching in conformance with peak power in internal mode as specified in laser system service manual must be

identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Black light
BNC cable
Expander lens
Laser safety goggles for
specified wave length
Laser system service manual

Oscilloscope Phosphor screen Pulse detector RF power meter Service report

- Review laser system service manual.
- 2. Put on laser safety goggles.
- 3. Energize laser and RF system.
- 4. Close shutter.
- 5. Place black light and phosphor screen in front of output mirror.
- 6. Install expander lens on front mirror mount.
- 7. Open shutter and observe that round beam appears on screen.
- 8. Turn PF mode switch to external position.
- 9. Verify disappearance of beam from screen.
 - a. Proceed as follows until beam disappears from screen:
 - (1) Verify RF power.
 - (2) Adjust bragg angle.
 - (3) Replace Q-switch on YAG laser.
 - (4) Replace RF driver.
- 10. Turn RF mode switch to CW (continuous wave) position.
- Verify reappearance of beam on screen.
 - a. Proceed as follows until beam reappears on screen.
 - (1) Check controller box and replace if necessary.
 - (2) Check mode switch and replace if necessary.
- 12. Turn RF mode switch to internal position.



PERFORMANCE OBJECTIVE NO.

TASK: Troubleshoot RF system (Continued)

- Set switch to desired repetition rate.
- 14. Connect pulse detector on rear mirror mount.
- 15. Connect BNC cable from pulse detector to oscilloscope.
- Verify that pulses appear on scope screen, and agree with switch setting.
 - Proceed as follows until pulses appear.
 - (1) Verify controller box operation.
 - (2) Verify RF driver output.
 - (3) Check for beam holdoff at external mode.
 - (4) Check for open or shorted BNC cable.
- 17. Check RF reflective power on RF meter.
 - Proceed as follows until RF reflective power is within laser system specifications.
 - (1) Match 50 MHZ Q-switch to RF driver box on YAG laser.
 - (2) Replace Q-switch on YAG laser.
 - (3) Replace RF driver.(4) Replace BNC cable.
- 18. Close shutter.
- 19. Remove black light and screen from beam path.
- 20. Remove expander lens and rulse detector.
- 21. Remove laser safety goggles.
- 22. Return laser system to service.
- 23. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 36

TASK: Troubleshoot vacuum system

STANDARD: All vacuum system leaks and vacuum pump operations

not in accordance with laser system specifications

must be identified.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Laser system service manual Safety glasses Service report
Spray bottle containing
manufacturer's specified
leak detector

- 1. Review laser system service manual.
- 2, Put on safety glasses.
- 3. Energize laser system.
 CAUTION: DO NOT ACTIVATE HIGH VOLTAGE.
- 4. Determine if vacuum gauge reading is above or below laser system's recommended range.
- Adjust gas flow to correct vacuum gauge reading.
- Observe vacuum gauge.
 - a. Proceed to step #7 if reading is in accordance with laser system specifications.
 - b. Proceed as follows if gauge registers zero until problem has been identified and corrected.
 - Check vacuum pump for defective fuse(s).
 - a. Replace defective fuse(s).
 - (2) Check circuit breaker.
 - a. Reset circuit breaker.
 - (3) Verify operation of vacuum pump.
 - a. Replace defective pump.
 - (4) Check for vacuum hose leaks.
 - a. Replace vacuum hose(s).
 - (5) Verify operation of gas flow gauge.
 - a. Replace defective gas flow gauge.
 - (6) Verify operation of gas soleroid(s).
 - a. Replace defective gas solenoid(s).



PERFORMANCE OBJECTIVE NO. 36

TASK: Troubleshoot vacuum system (Continued)

- c. Proceed as follows if reading is high or other than recommended until problem has been identified and corrected.
 (1) Turn off ass flow values
 - (1) Turn off gas flow valves.
 CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS
 CLOSED AND GAS BOTTLE IS SECURE.
 - (2) Observe vacuum gauge.
 Note: Gauge should indicate ± zero.
 - (3) Spray vacuum fittings, mirrors and valves with manufacturer's specified leak detector.
 - (4) Watch for increase in pressure on gauge.
 Note: Increase indicates leak.
 - (5) Repair area where increase in pressure is noted.
 - (6) Clean up excess spray solution.
- Purge vacuum system.
- 8. Remove safety glasses.
- 9 Return laser system to service.
- 10. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 37

TASK: Troubleshoot gas supply system

STANDARD: All gas supply system leaks must be identified. Gas

supply regulators and input pressure gas flow valves must be adjusted to laser system's specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Laser system service manual Safety glasses Service report Spray bottle containing manufacturer's specified leak detector

- 1. Review laser system service manual.
- 2. Put on safety glasses.
- Energize laser system.
 CAUTION: DO NOT ACTIVATE HIGH VOLTAGE.
- Locate gas supply regulators, supply lines, and flow gauges.
- 5. Turn on gas bottle valve.
- Listen for gas leaks.
 - a. Repair gas leaks if necessary.
- 7. Test each gas control flow valve by turning it off and on.
 - a. Repair or replace defective valve(s).
- Turn off gas bottle valve.
- 9. Turn off gas flow valves in laser system.
- Turn on gas bottle valve.
- Turn off gas bottle valve.
 - Note: Steps #8-11 should trap a small amount of gas.
- 12. Observe gas pressure gauge for pressure drop.
 - a. Proceed to step #13 if pressure is maintained.
 - b. Proceed as follows if pressure drops.
 - (1) Repair gas leaks.
 - (2) Repeat steps #8-11 if necessary.
- 13. Readjust all valves and flow valves to laser system specifications.
 - a. Replace gas regulator if pressure does not regulate.
 - b. Adjust pressure according to laser system specifications.



PERFORMANCE OBJECTIVE NO. 37

TASK: Troubleshoot gas supply system (Continued)

- 14. Remove safety glasses.
- 15. Return laser system to service.16. Prepare service report.

SOURCE FOR STANDARD:



DUTY: REPAIRING TEMPERATURE CONTROL SYSTEM

PERFORMANCE OBJECTIVE NO. 38

TASK: Replace cooler fitting(s)

STANDARD: Fittings must be clean and must not leak coolant.

Fittings must not be cross threaded.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses Fitting(s) Service report Shorting bar

Laser system service manual

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- Attach high voltage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to fitting(s).
- 8. Wipe clean all fittings and area around fitting(s) with rag.
- 9. Remove fitting(s).
- 10. Clean up coolant spillage with rag.
- 11. Apply teflon tape to new fitting threads.
- 12. Install new fitting(s).
- Check fitting(s) for cross threading.
 - a. Proceed as follows if fittings are cross threaded until problem has been corrected.
 - (1) Remove fitting
 - (2) Reinsert fitting
 - (3) Tap fitting in place
 - (4) Tighten fitting
 - (5) Replace fitting if it is still cross threaded.
- 14. Clean up any remaining coolant.
- 15. Remove shorting bar.
- 16. Connect main power cord.
- 17. Energize laser system.



PERFORMANCE OBJECTIVE NO. 38

TASK: Replace cooler fitting(s) (Continued)

- 18. Check fitting(s) for leaks. a. Retape leaking fitting(s).
- 19. Adjust coolant flow to flow rate recommended in laser system specifications.
- 20. Remove safety glasses.
- 21. Return laser system to service.
- 22. Prepare service report.23. Dispose of defective cooler fitting according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 39

TASK: Clean cooler fitting(s)

STANDARD: Fitting(s) must be clean and must not leak coolant.

Fitting(s) must not be cross threaded or damaged.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses Can of compressed air Service report High voltage probe Shorting bar Laser system service manual

PERFORMANCE GUIDE:

1. Put on safety glasses.

- 2. Shut down laser power supply.
- 3. Disconnect main power.

4. Insert shorting bar.

5. Attach high voltage probe.

6. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.

7. Gain access to fitting(s).

8, Wipe clean all fittings and area around fitting(s) with clean rag.

Remove fitting(s).

10. Clean up coolant spillage with rag.

Remove old teflon tape from fitting threads. 12.

Clean inside fitting(s).

Blow out fitting(s) with compressed air. 13

Apply teflon tape to fitting threads. 14

15 Reinstall fitting(s).

Check fitting(s) for cross threading. 16

- a. Proceed as follows if fittings are cross threaded until problem has been corrected.
 - (1) Remove fitting. (2) Reinsert fitting.
 - (3) Tap fitting in place.

(4) Tighten fitting.

Replace fitting if it is still cross threaded.

PERFORMANCE OBJECTIVE NO. 39

TASK: Clean cooler fitting(s) (Continued)

- 17. Clean up any remaining coolant.
- 18. Remove shorting bar.
- 19. Connect main power.20. Energize laser system.
- 21. Check fitting(s) for leaks.
 - a. Tighten leaking fitting(s), or
 - b. Retape leaking fitting(s).
- 22. Adjust coolant flow to flow rate recommended in laser system service manual.
- 23. Remove safety glasses.
- 24. Return laser system to service.
- 25. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 40

TASK: Recharge cooling system

STANDARD: Cooling system must have full charge of refrigeration

in sight glass when in cooling cycle with no air bubbles visible in sight glass. Compressor high side pressure must be in accordance with laser system

specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Cooler refrigerant Manifold gauges and hoses Service report

Laser system service manual Safety glasses

- Review laser system service manual.
- 2. Put on safety glasses.
- Energize system cooler.
- 4. Locate high and low pressure valves and fittings on cooler compressor.
- 5. Connect blue hose from manifold gauges to low side fitting on compressor.
- 5. Connect red hose from manifold gauges to high side fitting on compressor.
- 7. Connect yellow hose from manifold gauges to refrigerant supply tank fitting.
- 8. Turn on refrigerant main gas valve.
- 9. Bleed air from refrigerant supply toses.
- 10. Crack compressor low and high side valves open 1/2 turn.
- 11. Turn cooler control to cool cycle.
- 12. Locate refrigerant sight glass.
- 13. Open red hose pressure valve in accordance with laser system specifications.
- 14. Observe high side pressure gauge reading.
- 15. Open blue hose coolant supply valve in accordance with laser system specifications.
- Close all valves when high pressure gauge is in accordance with laser system pressure specifications.
- Observe coolant gas sight glass. Note: No air bubbles should appear.



PERFORMANCE OBJECTIVE NO. 40

TASK: Recharge cooling system (Continued)

- 18. Disconnect all gas hoses from system.
 CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS CLOSED AND GAS BOTTLE IS SECURE.
- 19. Readjust cooler temperature control to laser system specifications.
- 20. Remove safety glasses.
- 21. Return laser system to service.
- 22. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 41

TASK: Replace temperature sensor(s)

STANDARD: Thermal switch activation at laser system's specified

temperature must be verified. Sensors must be securely

mounted electrically and mechanically.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Heat gun High voltage probe Laser system service manual Safety glasses

Service report Shorting bar Temperature sensor Thermocouple meter VOM

- 1. Put on safety glasses.
- 2. Shut down complete laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAG BEEN DRAINED FROM SYSTEM.
- 7. Gain access to temperature sensors.
- Disconnect electrical wire to sensors.
- 9. Disconnect temperature sensor from housing.
- 10. Remove sensor from system.
- 11. Install new sensor in housing,
- 12. Connect electrical wires.
- 13 Connect vOM across temperature sensors.
- 14 Hold thermocouple meter near temperature switch.
- 15. Ture on heat gun and direct air to temperature sensors.
- Verify temperature sensor operation by thermocoupie meter reading.
- 17 Remove shorting bar.
- 18 Connect main power.



PERFORMANCE OBJECTIVE NO. 41

TASK: Replace temperature sensor(s) (Continued)

- 19. Remove safety glasses.20. Return laser system to service.21. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 42

TASK: Replace defective water pump

STANDARD: Mounting bolts and electrical wiring must be secure.

Water pump must not leak and must operate in conform-

ance with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit

High voltage probe
Laser system service manual
Safety glasses

Service report
Shorting bar
Water pump

- 1. Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to water pump.
- 8. Wipe pump area with clean rag.
- 9. Close supply and return water valves to pump.
- 10. Remove electrical wires.
- 11. Remove input and outlet water lines.
- 12. Remove water pump mounting bolts.
- 13. Remove pump from system.
- 14. Install new pump in system pump mount.
- 15. Secure pump in place with mounting bolts.
- 16. Connect inlet and outlet hoses.
- 17. Clean up any water spillage.
- 18. Connect electrical wires.
- 19. Open supply and return water valves.
- 20. Remove shorting bar.
- 21. Connect main power.
- 22. Energize laser.



PERFORMANCE OBJECTIVE NO. 42

TASK: Replace defective water pump (Continued)

- 23. Test water pump for leaks and operation. a. Troubleshoot temperature control system if necessary.
- 24.
- Remove safety glasses. Return laser system to service.
- 26. Prepare service report.
- Dispose of defective water pump according to facility 27. procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 43

TASK: Replace flow sensor

STANDARD: Mounting screws and electrical wiring must be secure.

Flow sensor must not leak coolant and must operate in

conformance with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit.

Clean rags
Flow sensor switch
High voltage probe

Laser system service manual
Safety glasses
Service report
Shorting bar

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- Attach high voltage probe.
- 6. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to flow sensor.
- 8. Shut off coolant supply and return valves.
- 9. Wipe area with clean rag.
- 10. Remove electrical wires.
- 11. Remove inlet and outlet coolant lines.
- 12. Remove flow sensor mounting screws.
- 13. Remove flow sensor from system.
- 14. Install new flow sensor in system mount.
- 15 Tighten mounting screws.
- 16. Replace inlet and outlet cooling lines.
- 17. Clean up spilled coolant.
- 18. Connect electrical wires.
- 19. Remove shorting bar.
- 20. Test flow sensor for coolant leaks and operation.
 - a. Tighten mounting screws and/or electrical wires if necessary.
 - o. Troubleshoot temperature control system if necessary.



PERFORMANCE OBJECTIVE NO. 43

TASK: Replace flow sensor (Continued)

- 21. Remove safety glasses.
- 22. Return laser system to service.
- 23. Prepare service report.
- 24. Dispose of defective flow sensor switch according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 44

TASK: Repair defective wiring

STANDARD: Continuity of wiring must be confirmed with ohmmeter.

All repaired wiring must be stripped and replacement connectors must be soldered or crimped on wire ends.

Wire must be continuous from terminal to terminal.

Replacement wire must be same color and specification as removed wire.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit

High voltage probe
Ohmmeter

Replacement wire
Replacement wire connectors
Safety glasses

Service report
Shorting bar
Solder
Soldering iron
Wire strippers

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 1. Gain access to defective wiring.
- 8. Locate raulty wiring termination and start points.
- 9. Remove defective wire from wiring harness.
- Cut equal length of new replacement wire of same color and gauge.
- 11. Strip ends of new wire.
- 12. Install new wire in harness.
- 13. Solder or crimp replacement connector(s) on wire ends.
- i4. Connect wire ends to start and terminate points.
- 15. Confirm continuity of wire using ohmmeter across wire.
- 16. Secure wire in wiring harness.
- 17. Remove shorting bar.



PERFORMANCE OBJECTIVE NO. 44

TASK: Repair defective wiring (Continued)

- 18. Connect main power.19. Remove safety glasses.
- 20. Return laser system to service.21. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 45

TASK: Replace defective hosing

STANDARD: Cooler hosing must not leak and must be secure in

system in conformance with laser system specifications.

All spillage must be removed.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage probe Laser system service manual Replacement nosing

Safety glasses Shorting bar Service report

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attac: high voltage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to defective hosing.
- 8. Measure length of defective hosing.
- 9. Measure and cut new length of hosing.
- 10. Turn off cooler supply and return flow valves.
- 11. Remove defective section of hose from unit.
- 12. Remove hose connectors from hose ends if applicable.
- 13. Put hose connectors on ends of new hose.
- 14. Install and secure new hose in system.
- 15. Open supply and return cooler flow valves.
- 16. Clean up any cooler water spillage.
- 17. Remove shorting bar.
- 18. Connect main power.
- 19. Turn cooler on.



PERFORMANCE OBJECTIVE NO. 45

TASK: Replace defective hosing (Continued)

- 20. Check system for:
 - a. Water leaks
 - b. Water level as recommended in laser system service manual
 - c. Operation according to laser system specifications(1) Troubseshoot temperature control system if necessary.
- 21. Remove safety glasses.
- 22. Return laser system to service.
- 23. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 46

TASK: Replace heat exchanger

STANDARD: All hoses and wires must be connected with temperature

sensor in place. Cooler reservoir must be refilled with steam distilled or deionized water. There must

be no leaks and spillage must be cleaned up.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Heat exchanger Laser system service manual Safety glasses Service report Steam distilled/deionized water

- 1. Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Shut down cooler pump.
- 4. Drain water from primary water loop.
- 5. Disconnect secondary input and output water lines from heat exchanger.
- 6. Disconnect primary input and output water hoses from top chamber of heat exchanger.
- Disconnect temperature sensor wires from heat exchanger to connector.
- 8. Remove temperature sensor from heat exchanger T connector.
- 9. Remove mounting bolts that hold down heat exchanger.
- Remove heat exchanger from cooler comparément.
- 11. Install new heat exchanger and bolt in place.
- 12. Install old temperature sensor onto new heat exchanger T
- 13. Reconnect secondary input and output water hoses onto new exchanger.
- 14. Reconnect temperature sensor wires.
- 15. Reconnect primary input and output hoses to exchanger.
- 16. Refill cooler reservoir.
 Note: Use steam distilled water or deionized water only.
- 17. Energize cooler pump.
- 18. Check for any leaks around fittings.



PERFORMANCE OBJECTIVE NO. 46

TASK: Replace heat exchanger (Continued)

- 19. Review laser system specifications.
- 20. Test water temperature.
 - a. Adjust if necessary
- 21. Remove safety glasses.
- 22. Return laser system to service.
- 23. Prepare service report.
- 24. Dispose of defective heat exchanger according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 47

TASK: Replace reservoir level switch

STANDARD: Cooler pump must cycle according to water level in tank.

Reservoir must be refilled to water line with steam

distilled deionized water.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Reservoir level switch Safety glasses

Service report
Steam distilled/deionized
water

PERFORMANCE GUIDE:

- 1. Put on safety glasses.
- 2. Shut down cooler pump.
- 3. Drain water from reservoir.
- 4. Disconnect molex electrical connector from level switch.
- Remove reservoir mounting strap to gain access to retainer nut.
- 6. Remove level switch retainer nut.
- 7. Pull level switch assembly out of reservoir.
- 8. Install new level switch down into reservoir.
- 9. Tighten retainer nut.
- 10. Reinstall and tighten reservoir mounting strap.
- 11. Reconnect molex electrical connector to level switch.
- 12. Refill reservoir with water up to water level line. Note: Use deionized or steam distilled water only.
- 13. Turn on cooler pump.
- 14. Remove safety glasses.
- 15. Return laser system to service.
- 16 Prepare service report.
- 17. Dispose of defective reservoir level switch according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 48

TASK: Replace agitator

STANDARD: Agitator must be mechanically and electrically secure.

Agitator must agitate cooling water in cooler reservoir.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Agitator High voltage probe Safety glasses Service report Shorting bar

PERFORMANCE GUIDE:

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to cooler agitator and wiring.
- 8. Remove motor voltage supply lines.
- 9. Remove agitator propeller from agitator motor shaft.
- 10. Remove agitator mounting bolts.
- 11. Remove agitator from cooler unit mount.
- 12. Install new agitator in mount.
- 13. Install agitator mounting bolts.
- 14. Install old propeller on new gitator motor shaft.
- 15. Connect motor voltage supply wires.
- 16. Ensure that agitator propeller and shaft turn freely.
- 17. Remove shorting bar.
- 18. Connect main power
- 19. Turn on cooler.
 - a. Troubleshoot temperature control system if necessary.
- 20. Verify agitator operation.
- 21. Remove safety glasses.
- 22. Return laser system to service.
- 23. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 49

TASK: Replace water solenoid(s)

STANDARD: Water solenoid(s) must be mechanically and electrically

secure. All spilled coolant must be removed and recommended coolant level must be replenished.

Solenoid must control flow of coolant in conformance

with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses
Coolant Service report
High voltage probe Shorting bar
Laser system service manual Water solenoid(s)

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7, Close cooler inlet and outlet flow valves.
- 8, Gain access to water solenoid(s).
- 9. Remove solenoid voltage wires.
- 10. Remove inlet coolant line,
- 11. Remove outlet coolant line.
- 12. Remove solenoid from mounting bracket,
- 13 Install new solenoid in mounting bracket.
- 14. Connect solenoid voltage wires.
- Replace coolant inlet line.
- 16. Replace coolant outlet line.
- 17. Clean up spilled coolant with rag.
- 18 Open cooler inlet and outlet cooler flow valves.
- 19. Replenish any lost coolant.
- 20. Test solenoid(s) for coolant leaks.
- 21. Rerove shorting bar



PERFORMANCE OBJECTIVE NO. 49

TASK: Replace water solenoid(s) (Continued)

- 22. Remove safety glasses.23. Return laser system to service.
- 24. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 50

TASK: Replace crystal rod

STANDARD: Crystal rod must be clean and secure in laser housing

with no water leaks on rod faces when cooler is turned on. Laser threshold and power at establishing running

current must be in conformance with laser system

specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Clean air hood
Crystal rod
Laser system service manual
Methyl alcohol
O-rings
Retainer spanner wrench
(special)

Rod depth insertion tube Safety glasses Service report Surgical gloves VOM

- 1. Put on safety glasses.
- 2. Shut down laser supply.
- 3. Shut down cooler pump.
- 4. Disconnect main power.
- 5. Remove left and right beam tubes from rod ends.
- 6. Remove hex screws from pressure plates.
- 7. Remove left and right lamp jacket pressure plates and 0-rings.
- 8. Set up clean air hood.
- 9. Tape both ends of rod jacket before removing rod assembly from laser housing.
 - Note: Protect rod from dirt and water.
 Remove crystal rod assembly from housing.
- 11. Place crystal rod assembly under air hood.
- 12. Loosen right lock nut.
- 13. Remove crystal from right pressure tube 0-ring.
- 14. Wash hands.
- 15. Remove right side pressure tube retainer ring.
- 16. Replace and tighten lock nut.
- 17. Loosen right pressure tube set screw.
- 18. Loosen left side lock nut.



PERFORMANCE OBJECTIVE NO. 50

TASK: Replace crystal rod (Continued)

- 19. Grasp right side pressure tube hardware with lens tissue and carefully pull out of left side pressure tube 0-ring.
- 20. Remove crystal from jacket assembly.

 Note: Use surgical gloves or similar precautions in handling crystal rod.
- 21. Loosen right lock nut.
- 22. Remove crystal from right pressure tube 0-ring.
- 23. Clean replacement rod body and coated ends.

 Note: Standard procedure on cleaning optical surfaces must be followed.
- 24. Replace right pressure tube 0-ring on rod depth insertion tube.
- 25. Insert rod depth insertion tube into pressure tube housing.
- 26. Slip right lock nut on pressure tube housing.
- 27. Insert one end of rod into rod depth insertion tube and seat.
- 28. Tighten right lock nut.
 Note: 0-ring should compress and water seal rod end.
- 29. Replace left U-ring in left pressure tube housing.
- 30. Loosen left pressure tube lock nut.
- 31. Insert crystal rod into crystal jacket and pass rod into left pressure tube housing 0-ring.
- 32. Tighten left lock nut.
- 33. Loosen right lock nut and remove.
- 34. Remove rod depth insertion tube.
- 35. Replace with metal pressure tube.
- 36. Replace and tighten retainer ring.
- 37. Install left and right lock nuts and tighten.
- 38. Reinstall crystal jacket assembly back into laser housing.
- 39. Reinstall crystal jacket left and right 0-rings and pressure plates.
- 40. Tighten plates.
- 41. Review laser system specifications.
- 42. Energize laser.
- 43. Check for water leaks.
- 44. Test power/energy output at source.
- 45. Remove safety glasses.



PERFORMANCE OBJECTIVE NO. 50

TASK: Replace crystal row (Continued)

- 46. Return laser system to service.
- 47. Prepare service report.
- 48. Dispose of defective crystal rod according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 51

TASK: Replace gaseous tube

STANDARD: Front and rear caps must be secure on laser housing.

Wires must be connected between new gaseous tube and

tube housing. Gaseous tube must discharge.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Shorting bar

Laser system service manual Silicone high vacuum grease

Laser tube Solder

0-rings Soldering iron
Safety glasses Spanner wrench

Service report

PERFORMANCE GUIDE:

Gaseous Laser Without Water Cooler Component:

- 1. Put on safety glasses.
- 2, Shut down laser power supply.
- 3. Disconnect main power.
- 4. Turn off gas supply valve.
 CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS CLOSED AND GAS BOTTLE IS SECURE.
- 5. Remove front cap from laser housing.
- 6. Remove rear cap from laser housing.
- 7. Remove laser tube mounts.
- 8. Slide laser tube out of housing.
- 9. Disconnect wires from laser tube.
- Discard pad tube according to facility procedure.
- 11. Connect wires to new laser tube.
- 12. Solder wires.
- 13. Slide laser tube into housing.
- 14. Replace tube mounts.
- 15. Realign cavity if necessary.
- 16. Remount front cap onto laser housing.
- 17. Kemount rear cap onto laser nousing.
- 18. Turn on gas supply valve.
- 19. Energize laser.



PERFORMANCE OBJECTIVE NO. 51

TASK: Replace gaseous tube (Continued)

- 20. Check laser tube operation,
 - Troubleshoot beam generation system if laser does not perform in conformance with laser system specificatior.
- 21. Purge vacuum system.
- 22. Remove safety glasses.
- 23. Return laser system to service.
- 24. Prepare service report.

Gaseous Lasers With Water Cooler Component:

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Shut off gas supply valve. CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS CLOSED AND GAS BOTTLE IS SECURE.
- 8. Gain access to gaseous tube,
- 9. Remove high voltage wires.
- 10. Remove front and rear mirror assembly.
- il. Remove supply and return cooler lines.
- 12. Remove gas supply and return hoses.
- 13. Loosen gaseous tube and water jacket mounting brackets.
- 14 Remove tube from laser head.
- 15. Drain water from gaseous tube water jacket.
- Remove water jacket(s) locking nuts and 0-rings with spanner wrench.
- 17. Remove gaseous tube from water jacket.
- 18. Discard bad tube according to facility procedure.
- 19. Insert new tube in water jacket.
- 20. Grease 0-ring.
- 21. Install O-ring to gaseous tube.
- 22. Place locking nuts on gaseous tube.
- 23. Tighten nuts with spanner wrench.
- 24. Place gaseous tube in laser head mounting brackets,
- 25. Realign optics cavity.



PERFORMANCE OBJECTIVE NO

TASK: Replace gaseous tube (Continued)

- 26. Connect vacuum inlet and outlet hoses.
- 27. Connect supply and return cooler lines.
- 28. Tighten gaseous tube mounting brackets.
- 29. Install front and rear mirror mounts. 30. Connect high voltage wires.
- 31. Realign complete beam delivery path.
- 32. Remove shorting bar.33. Connect main power.
- 34. Energize laser.
- 35 Test system for water leaks.
 - a. Repair leaks.
- 36. Test system for vacuum leaks.
 - a. Troubleshoot vacuum system.
- 37. Purge vacuum system.
- 38. Check power output.
 - a. Adjust power to meet laser system specifications.
- 39. Remove safety glasses.
- 40 Return laser system to service.
- 41. Prepare service report,

SOURCE FOR STANDARD:



1

DUTY: REPAIRING BEAM GENERATION SYSTEM

PERFORMANCE OBJECTIVE NO. 52

TASK: Replace mirror(s)

STANDARD: Mirror must be secure in mount with mirror peak

controls locked in place. Mirrors must be aligned

for optimum power and mode as specified in laser system

service manual.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit lahe1

Laser safety goggles for specified wave length Laser system service manual

Lens tissue

Methyl alcohol

Mirror Mirror box

Mirror holder tool Mirror removal-retainer

Operational log book

Service report

PERFORMANCE GUIDE:

- Shut down laser power supply.
- 2. Wash hands.
- 3. Put on laser safety goggles.
- 4. Remove mirror retainer ring from mirror mount.
- 5. Remove mirror using mirror holding tool.
- 6. Place old mirror in mirror box.
- 7. Label status of mirror in operational log book.
- Place new mirror into holder tool.
- 9. Clean mirror on both sides.
- Install new mirror into mount. Note: Mirror arrow should point in toward rod.
- 11. Replace and tighten retainer ring.
- 12. Realign laser cavity.
- 13. Energize laser,
- Repeak mirror for optimum power according to laser system specifications.
- 15. Lock mirror peak controls.
- 16. Remove laser safety goggles.
- 17. Return laser system to service.
- 18. Prepare service report.
- Dispose of defective mirror according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 53

TASK: Replace gold cavity

STANDARD: Block assembly must be secure in housing. Anode and

cathode wires must be connected, and laser must be free of leaks. Laser threshold and power must be in

conformance with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Adjustable jack stand(s)
Black light
End cap pin holes
Expander lens

Gold cavity Helium neon alignment laser Laser safety goggles for specified wave length Laser system service manual O-rings

Phosphor screen Service report

- 1. Review laser system service manual.
- 2. Shut down laser power supply.
- 3. Wash hands.
- 4. Put on laser safety goggles.
- 5. Remove anode and cathode wires from lamp jacket assembly.
- 6. Remove left and right lamp jacket pressure plates.
- 7. Remove left and right beam tubes from crystal jacket ends.
- 8. Remove pressure plates and 0-rings from left and right sides of crystal jacket ends.
- 9. Remove crystal jacket rod assembly from laser housing.
- 10. Remove lamp jacket assembly from laser housing.
- 11. Remove top cover of laser housing assembly.
- 12. Remove gold cavity block assembly.
- 13. Remove both left and right gold end plates from gold cavity block assembly.
- 14. Separate two halves of gold cavity block assembly.
- 15. Remove gold cavity.
- 16. Install new gold cavity into gold cavity block halves.
- 17. Tighten in place.
- 18. Install left and right end plates onto block assembly.
- 19. Insert entire block assembly back into laser housing.
- 20. Tighten block assembly.



PERFORMANCE OBJECTIVE NO. 53

TASK: Replace gold cavity (Continued)

- 21. Install laser housing cover.
- 22. Tighten screws down evenly to prevent water leaks.
- 23. Replace lamp jacket assembly pressure plates.
- 24. Install lamp jacket assembly.
- 25. Install new C-rings.
- 26. Replace crystal jacket assembly pressure plates.
- 27.
- Install crystal jacket assembly.
 Reposition anode and cathode wires on lamp jacket. 28.
- 29. Replace left and right beam tubes in crystal rod assembly.
- 30. Turn laser cooler pump on.
- Check for water leaks. 31.
- 32, Realign laser.
- 33. Remove laser safety goggles.
- 34. Return laser system to service.
- Prepare service report. 35.
- Dispose of defective gold cavity according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 54

TASK: Replace electrode(s)

STANDARD: Electrical and mounting screws must be secure and laser

system must operate in conformance with laser system

specifications.

CONDITIONS FOR PERFORMANCE OF TACK:

Standard tool kit
Electrode(s)
Service report
Shorting bar
Laser system service manual
Vacuum fore pump

Oscilloscope

- 1. Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to electrode(s).
- 8. Wipe access area with clean ray.
- 9. Wash hands,
- 10. Remove electrode electrical and mounting screw(s).
- 11. Pull electrode(s) from plasma tube.
 - Note: Care must be taken to avoid damage to plasma tube.
- 12. Install new electrode(s).
- 13. Screw in electrical and mounting screw(s).
- 14. Purge vacuum system.
- Remove shorting bar.
- 16. Connect main power.
- 17. Energize laser.
- 18. Test operation of laser system.
 - a. Troubleshoot beam generation system if necessary.
- 19. Remove safety glasses.



PERFORMANCE OBJECTIVE NO. 54

TASK: Replace electrode(s) (Continued)

- 20. Return laser system to service.
- 21. Prepare service report.
- 22. Dispose of defective electrode(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE GBJECTIVE NO. 55

TASK: Replace polarizer

STANDARD: Polarizer must be secure and aligned with beam path.

Laser output must be polarized as specified in laser

system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Adjustable jack stands
Black light
End cap pin holes
Expander lens
Laser power meter
Laser system service manual

Lens tissue
Methyl alcohol
Phosphor screen
Polarizer plates
Helium neon alignment laser
Safety glasses

Service report

PERFORMANCE GUIDE:

- I. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4 Remove screws from top cover of polarizer.
- 5 Remove allen screws from Brewster block assembly.
- 6. Pull Brewster block assembly up out of mounting cube.
- Loosen set screws.
- 8 Remove polarizer optic plates.
- Clean both sides of new polarizer plates.
 Note: Use only methyl alcohol and lens tissue.
- 10. Install new polarizer plates onto Brewster block assembly.
- II. Install Brewster block into mounting cube.
- 12 Tighten Brewster block.
- 13 Replace and tighten cover.
- 14. Align optics.
- 15. Purge vacuum system.
- 16. Remove safety glasses.
- i7. Return laser system to service.
- 18. Prepare service report.
- 19. Dispose of defective polarizer according to facility procedure.

SOURCE FOR STANDARD.



PERFORMANCE OBJECTIVE NO. 56

TASK: Replace Q-switch

STANDARD: Q-switch must hold off beam with continuous RF on and

Q-switch in pulse position. Power output must be within laser system's specified range with bragg angle

adjusted for minimum output.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Adjustable jack stands
Black light
End cap pin holes
Expander lens
Helium neon alignment laser
Laser power meter

Laser safety goggles for specified wave length Laser system service manual Phosphor screen Q-switch Service report

- 1. Review laser system service manual.
- 2. Put on laser safety goggles.
- Shut down laser system. CAUTION: IF Q-SWITCH HAS EXTERNAL RF DRIVER BOX, MAKE SURE RF MODE SWITCH IS IN "OFF" POSITION.
- 4. Disconnect main power.
- 5. Remove RF cable from Q-switch assembly.
- 6 Remove left and right beam tubes from O-switch assembly.
- 7 Remove allen screws from Q-switch base plate.
- 8. Lift and remove Q-switch from laser rail.
- 9. Place new Q-switch on rail.
- 10. Replace and tighten allen screws.
- 11. Connect RF cable to Q-switch.
- 12. Energize laser system.
- 13. Realign Q-switch to laser axis.
- 14. Turn on RF power to external position.
- 15. Measure power out with power meter.
- 16. Adjust bragg angle control for minimum output.
- 17. Switch mode to Q-switch position on driver box.
- 18. Replace left and right beam tubes.
- 19. Remove laser safety goggles.



PERFORMANCE OBJECTIVE NO. 56

TASK: Replace Q-switch (Continued)

- 20. Return laser system to service.
- 21. Prepare service report.
- 22. Dispose of defective Q-switch according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 57

TASK: Repair beam expander

STANDARD: Both positive and negative lenses must be clean and

free of burns. Laser output power must return to laser

system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Methyl alcohol Laser system service manual Safety glasses Lens tissue Service report

PERFORMANCE GUIDE:

1. Put on safety glasses.

2. Shut down laser power supply.

3. Loosen hand lock ring on beam expander.

- 4. Unscrew beam expander counterclockwise from laser front mirror mount.
- 5. Observe both positive and negative lenses for burns or dirt.
- 6. Clean lens with methyl alcohol and lens tissue.
- 7. Replace burnt lens if necessary.
 - a. Remove negative lens retainer ring.
 - b. Remove lens with tweezers.
 - c. Clean and install new lens with tweezers. Note: Observe direction of lens curvature prior to removal of lens.
 - d. Install and tighten retainer ring.
- Repeat steps #5-7 for positive lens replacement.
- 9. Reinstall beam expander on front mirror mount.
- O Screw beam expander on clockwise.
- ll. Tighten hand lock ring.
- 12. Energize laser.
- Adjust power supply to recommended running current according to laser system specifications.
- 14. Remove safety glasses.
- 15. Return laser sytem to service.
- 16. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 58

TASK: Replace mirror mount

STANDARD: Mirror mount must be tight and centered on laser beam

axis. Peaking knobs must move freely.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit

Adjustable jack stands

Black light

End cap pin holes

Expander lens

Helium neon alignment laser

Laser system service manual

Mirror mount

Mirror mount retainer

Phosphor screen

Safety glasses

Service report

PERFORMANCE GUIDE:

- 1. Put on safety glasses.
- Shut down laser power supply.
- 3. Pull rear beam tube out of rear mirror mount.
- 4. Wash hands.
- 5. Remove mirror cell from old mount and transfer to new mount.
- 6. Remove hex screws from mirror mount laser base plate.
- 7. Remove old mirror mount.
- 8. Install new mirror mount.
- 9. Replace and tighten down hex screws.
- Check that horizontal and vertical peaking knobs move freely without sticking.
- 11. Realign rear mirror to crystal rod axis.
- 12. Replace rear beam tube into rear mount.
- 13 Repeat steps #4-11 to replace front mirror mount.
- 14. Remove safety glasses.
- 15 Return laser system to service
- 16. Prepare service report.
- 17. Dispose of defective mirror mount according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 59

TASK: Replace laser housing assembly

STANDARD: Laser housing must be secured to casting with no

water leaks. Laser threshold and power at established

current must be in conformance with laser system

specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Adjustable jack stands
Black light
End cap pin holes
Expander lens
Helium neon alignment laser

Laser housing assembly Laser system service manual Phosphor screen Safety glasses Service report

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Remove water hose from inlet manifold.
- 5 Drain water from housing into reservoir.
- Remove water hose from output manifold.
- 7 Disconnect lamp wires from lamp jacket assembly.
- 8. Remove left and right beam tubes from crystal jacket ends.
- 9. Remove tie-down screws from housing brackets to laser casting.
- 10 Lift out entire laser housing assembly from laser casting.
- Remove top housing cover.
- 12 iransfer laser components to new laser housing assembly:
 - a Inlet manifold and O-ring
 - D. Output manifold and O-ring
 - c Top cover 0-ring
 - d. Gold cavity block assembly
 - e. Lamp sleeves
 - f. Lamp jacket assembly and pressure plates CAUTION: OBSERVE POLARITY OF LAMP WHEN INSERTING IN NEW HOUSING.
 - g. Crystal jacket assembly and pressure plates
 - h, Top cover
 - i. Left and right housing tie-down brackets.



PERFORMANCE OBJECTIVE NO. 59

TASK: Replace laser housing assembly (Continued)

- 13. Reinstall entire housing assembly back onto laser casting.
- 14. Tighten housing assembly.
- 15. Attach input-output hoses to manifolds.
- 16. Tighten hoses.
- 17. Connect lamp wires to lamp jacket ends.
- 18. Turn on cooler.
- 19. Check for water leaks and correct if necessary.
- 20. Review laser system specifications.
- 21. Energize laser.
- 22, Check for lamp ignition.
- 23. Realign laser.
- 24. Remove safety glasses.
- 25. Return laser system to service.
- 26. Prepare service report.
- 27. Dispose of defective housing assembly according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 60

TASK: Replace flash lamp

STANDARD: Flash lamp must ignite and remain lit. Lamp glass

must be clean and lamp retainer must be free of leaks. Laser threshold and power at established running current must be in conformance with laser system

> Lens tissue Methyl alcohol

> Safety glasses

Service report

Shorting bar

MOV

specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Flash lamp
High voltage probe
Lamp extraction tool
Lamp retainer spanner wrench
Lamp seating tool
Laser system service manual

- 1. Put on safety glasses.
- 2. Shut down lase, power supply.
- Insert shorting bar.
- 4. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 6. Shut down power to cooler.
- 7. Remove lamp power electrode from lamp jacket.
- 8. Remove lamp retainer from lamp jacket end.
- 9. Extract lamp from lamp jacket.
- 10. Clean glass area of new lamp.
- Insert lamp into lamp jacket, matching polarization of lamp and lamp jacket.
- Seat lamp securely into electrode lamp socket.
- 13. Reinstall lamp retainer.
 - Note: Tighten securely to prevent water leaks.
- 14. Reinstall power electrode in lamp socket end. CAUTION: HIGH VOLTAGE PRESENT.
- 15. Tighten securely to prevent arcing.
- 16. Turn cooler pump on.
- 17. Check for leaks.



PERFORMANCE OBJECTIVE NO. 60

TASK: Replace flash lamp (Continued)

- 18. Review laser system service manual.
- 19. Remove shorting bar.
- 20. Energize laser.
- 21. Check that lamp ignites and remains lit.
- 22. Remove safety glasses.23. Return laser system to service.
- 24. Prepare service report.
- 25. Dispose of defective lamp jacket according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 61

TASK: Replace lamp jacket

STANDARD: Flash lamp must light and remain lit. Lamp glass

must be clean and lamp retainer must be free of leaks. Laser threshold and power at established running current must be in conformance with laser

system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Laser system service manual

Standard tool kit
High voltage probe
Lamp extraction tool
Lamp jacket
Lamp retainer spanner wrench
Lamp seating tool

Lens tissue
Methyl alcohol
O-rings
Safety glasses
Service report
Shorting bar

- Put on safety glasses.
- 2. Shut down laser power supply.
- Insert shorting bar.
- 4. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- . Shut down power to cooler.
- 7. Remove lamp power electrode from lamp socket.
- 8. Remove flash lamp from lamp jacket.
- 9. Remove hex screws from left pressure plates.
- Remove outer pressure plate.
- 11. Remove thin O-ring from lamp jacket end.
- 12. Remove inner pressure plate.
- 13. Remove thick O-ring from lamp jacket end.
- 14. Repeat steps #9-13 for right side pressure plates.
- 15. Pull lamp jacket completely out of laser housing.
- 16. Insert new lamp jacket into laser housing.
- 17. Replace thick O-ring.
- 18. Place thick O-ring back over left side of lamp jacket.
- 19. Install inner pressure plate back over lamp jacket.
- 20. Replace thin 0-ring.



PERFORMANCE OBJECTIVE NO. 61

TASK: Replace lamp jacket (Continued)

- 21. Place thin O-ring over jacket end.
- 22. Install outer pressure plate back over lamp jacket.
- 23. Install hex screws through both pressure plates and tighten using lock washer and flat on each screw.
- 24. Repeat steps #17-23 for right side of jacket.
- 25. Clean lamp glass prior to insertion.
- 26. Insert lamp into jacket matching polarization of lamp and lamp jacket.
- 27. Seat lamp securely into electrode lamp socket.
- 28. Reinstall lamp retainer securely.
- 29. Reinstall power electrode in lamp socket end.
 CAUTION: POWER ELICTRODE MUST BE FIRM TO PREVENT ARCING.
- 30. Turn cooler pump on.
- 31. Check for water leaks.
- 32. Review laser system specifications.
- 33. Remove shorting bar.
- 34. Energize laser.
- 35. Check that lamp ignites and remains lit.
- 36. Remove safety glasses.
- 37. Return laser system to service.
- 38. Prepare service report.
- 39 Dispose of defective lamp jacket according to facility procedure

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 62

TASK: Collimate beam expander

STANDARD: Diameter of beam must be equal when compared at

8 feet and at 4 inches.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Black light Laser safety goggles for specified wave length Laser system service manual Phosphor screen Service report

- Energize laser to recommended operating current as per laser system service manual.
- 2. Put on laser safety goggles.
- 3. Close laser shutter internally.
- 4. Place phosphor screen 4 inches from beam expander output.
- 5. Turn on black light to illuminate screen.
- 6. Open internal shutter.
- 7. Note diameter of beam on screen.
- 8. Move screen and black light out to a distance of 8 feet.
- 9. Note diameter of beam on screen.
- 10. Compare diameter of beam at 8 feet and at 4 inches.
 - a. Proceed as follows if diameter of beam is larger at 8 feet than at 4 inches.
 - (1) Loosen lock ring on positive lens.
 - (2) Rotate lens clockwise one turn or more.
 - (3) Recheck beam diameter at 8 feet and at 4 inches.
 - (4) Repeat steps # (2) and (3) until diameter is equal at both distances.
 - (5) Tighten lock ring when diameter is equal.
 - b. Proceed as follows if diameter of beam is smaller at 8 feet than at 4 inches:
 - (1) Loosen lock nut on positive lens.
 - (2) Rotate lens counter clockwise one turn or more.
 - (3) Recheck beam diameter at 8 feet and at 4 inches.
 - (4) Repeat steps #b.(2) and b.(3) until diameter is equal at both distances.
 - (5) Tighten lock ring when diameter is equal.



PERFORMANCE OBJECTIVE NO. 62

TASK: Collimate beam expander (Continued)

- 11. Close internal shutter.
- 12. Remove laser safety goggles.13. Return laser system to service.
- 14. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 63

TASK: Verify peak pulse power

STANDARD: Calculated peak pulse power must be in conformance

with peak pulse power recommended in laser system

service manual.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Frequency counter
Laser power meter
Laser safety goggles for
specified wave length

Laser system service manual Operational log book Oscilloscope Pulse detector Service report

PERFORMANCE GUIDE:

- 1. Energize laser system.
- 2. Adjust running current to recommended current specified in laser system service manual.
- 3. Put on laser safety goggles.
- 4. Attach laser power meter.
- 5. Check that laser is Q-switching.
- 6. Measure power out of front mirror.
- 7. Record reading in operational log book.
- 8. Install laser pulse detector on rear mirror mount.
- 9. Attach oscilloscope.
- Record pulse width reading from oscilloscope in operational log book.
- 11. Connect frequency counter into sync out connection on back of RF driver.
- 12 Record counter reading in operational log book.
- 13. Multiply pulse width reading times frequency reading.
- 14. Divide result into power reading.
- 15. Compare calculation with peak power pulse specified in laser system specifications. Note: Calculation and specified peak power pulse must be equal.
- 16. Shut down laser.
- 17. Remove laser safety goggles.
- 18. Return laser system to service.
- 19. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 64

TASK: Verify frequency of pulse train

STANDARD: Deviation between frequency counter reading and dial

setting on RF must be within laser system specifica-

tions.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit

Frequency counter
Laser system service manual
Operational log book

Oscilloscope
Pulse detector
Safety glasses
Service report

- 1. Put on safety glasses.
- 2. Energize laser system.
- 3. Operate laser at running current specified in laser system service manual.
- 4. Install pulse detector in beam path for front mirror mount.
- 5. Connect cable from pulse detector output to oscilloscope input.
- 6. Check that laser is Q-switching and pulse chain appears on scope screen.
- 7. Set RF driver control dial to desired repetition rate. Note: Setting range 100 hertz to 80 kilohertz.
- 8. Observe oscilloscope to verify pulse chain is stable.
- Connect frequency counter input to RF driver sync output, with BNC cable.
- 10. Turn on counter
- 11. Record reading from counter in operational log book.
- 12. Record reading on dial setting in operational log book.
- 13. Compare readings:
 - a. Proceed to step #14 if readings are in conformance with laser system specifications.
 - b. Troubleshoot RF system if readings do not conform to laser system specifications.
- 14. Install pulse detector on rear mirror mount.
- 15. Repeat steps #5-13 for rear mirror mount verification of frequency of pulse train.



PERFORMANCE OBJECTIVE NO. 64

TASK: Verify frequency of pulse train (Continued)

- 16. Remove safety glasses.17. Return laser system to service.18. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 65

TASK: Replace high voltage capacitors

STANDARD: High voltage capacitors must be securely connected

and must be installed according to laser system

specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
High voltage capacitors
High voltage probe
Laser system service manual

Safety glasses Service report Shorting bar

- 1. Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove high voltage power supply from extrusion.
- 8. Remove defective capacitor from circuit.
- 9. Insert replacement high voltage capacitor(s) in circuit according to laser system service manual.
- 10. Secure high voltage capacitor in circuit.
- 11. Return high voltage power supply to extrusion.
- 12. Remove shorting bar.
- 13. Connect main power.
- 14. Energize laser.
- 15. Listen for arcing. Proceed as follows until problem has been corrected if laser is arcing:
 - a. Ensure that all cables are away from grounding surfaces.
 - b. Check potting compound for breakdown or degradation.(1) Repair if necessary.
 - c. Troubleshoot excitation system if necessary.



PERFORMANCE OBJECTIVE NO. 65

TASK: Replace high voltage capacitors (Continued)

- 16. Remove safety glasses.
- 17. Return laser system to service.
- 18. Prepare service report.19. Dispose of defective capacitor(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 66

TASK: Replace high voltage diodes

STANDARD: Soldered joint must be shiny and smooth. Diodes

must be installed with negative and positive polarity

in conformance with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
High voltage probe
Laser system service manual
Needle nose pliers
Safety glasses

Shorting bar Solder Soldering iron Solder puller Wire cutters

PERFORMANCE GUIDE:

1. Put on safety glasses.

Service report

- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove excitation circuit from extrusion.
- 8. Heat solder joints of diode(s) with soldering iron.
- 9. Remove solder from solder joint with solder puller.
- Remove defective diode(s).
 - Note: Observe polarity of diode prior to removal.
- 11. Place new diode in board observing polarity of previous diode.
- 12. Heat solder joint(s) with soldering iron.
- 13. Solder joint until soldered joint is shiny and smooth.
- 14. Cut excess diode leads close to soldered joint.
- 15. Return excitation circuit to extrusion.
- 16. Remove shorting bar.
- 17. Connect main power.
- 18. Energize laser.
- 19. Review laser system service manual.



PERFORMANCE OBJECTIVE NO. 66

TASK: Replace high voltage diodes (Continued)

- 20. Measure high voltage power output.
 a. Adjust voltage to meet laser system specifications.
- 21. Remove safety glasses.
- 22. Return laser system to service.
- 23. Prepare service report.
- 24. Dispose of defective high voltage diode(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 67

TASK: Replace SCR (silicon control rectifier)

STANDARD: SCR must be secure. Soldered joints must be smooth

and shiny. Polarity must be consistent with laser

Service report

Soldering iron

Shorting bar

Solder

VOM

system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Heat sink compound High voltage probe Laser system service manual Safety glasses

PERFORMANCE GUIDE:

1. Put on safety glasses.

2. Shut down laser power supply.

3. Disconnect main power. 4. Insert shorting bar.

5. Attach high voltage probe.

Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.

7. Remove laser supply bottom cover.

8. Loosen and remove nut from cathode of SCR.

9. Remove wire lug from cathode stud.

10. Unsolder and remove anode wire from SCR. Unsolder and remove gate wire from SCR. 11.

Remove SCR from mounting bracket. 12、

Check that mica insulator is not damaged on bracket. 13.

a. Replace damaged insulation if necessary.

Apply heat sink compound to new SCR cathode mounting base.

15. Install new SCR into mounting bracket.

16. Install and tighten nut on SCR.

17. Attach VOM.

Test to ensure that SCR cathode is electrically isolated from chassis bracket.

19. Solder anode wire back on new SCR.

20. Solder gate wire back on new SCR.

Repeat steps #8-20 to replace other defective SCRs.



PERFORMANCE OBJECTIVE NO. 67

TASK: Replace SCR (silicon control rectifier) (Continued)

- 22. Replace laser supply bottom cover.
- 23. Remove shorting bar.
- 24. Connect main power.
- 25. Energize laser.
- 26. Remove safety glasses.
- 27. Review laser system specifications.
- 28. Return laser system to service.
- 29. Prepare service report.
- 30. Dispose of defective SCR according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 68

TASK: Replace defective board(s)

STANDARD: Input and output connectors must be securely connected

and all mounting screws must be tightened to chassis.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit

Board(s)

High voltage probe Safety glasses

Service report Shorting bar

MOV

PERFORMANCE GUIDE:

- Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove bottom laser supply cover.
- 8. Disconnect input connector from board.
- 9. Disconnect output connector from board.
- 10. Remove mounting screws from board.
- 11. Remove defective board.
- 12. Install new board.
- 13. Install mounting screws into new board.14. Tighten screws to chassis.
- 15. Connect input connector.
- 16. Connect output connector.
- 17. Replace bottom laser supply cover.
- 18. Remove shorting bar.
- 19. Connect power cable.
- 20. Energize laser.
- 21. Remove safety glasses.
- 22. Return laser system to service.
- 23. Prepare service report.
- 24. Dispose of defective board(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 69

TASK: Repair defective board(s)

STANDARD: Board(s) must operate in conformance with specifica-

tions. All soldered joints must be smooth and shiny.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
High voltage probe
Laser system service manual
Oscilloscope
Safety glasses

Service report Shorting bar Solder Soldering iron

Wire

PERFORMANCE GUIDE:

- 1. Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove defective board(s) from extrusion.
- Inspect boards for cracks or broken or lifted trace(s).
 - a. Remove loose trace(s).
 - b. Solder wire to bridge broken board(s).
 - c. Replace cracked or broken board(s).
- 9. Return board to extrusion.
- 10. Remove shorting bar.
- 11. Connect main power.
- 12. Energize laser.
- 13. Verify board operation.
 - a. Troubleshoot excitation system if power supply does not operate in conformance with laser system specifications.
- 14. Remove safety glasses.
- 15. Return laser system to service.
- 16. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 70

TASK: Replace high voltage cable(s)

STANDARD: Cable(s) must be securely connected and tube mounts must be tight. Laser system must operate without

arcing, at recommended running current as specified

in laser system service manual.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage cable High voltage probe Laser system service manual Safety glasses Service report Shorting bar

- 1. Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Disconnect high voltage cable from high voltage power supply.
- 8. Remove rear end cap on laser tube housing.
- 9. Remove front cap on laser tube housing.
- 10. Loosen tube mounts.
- 11. Slide tube out of housing.
- 12. Disconnect high voltage cable(s) from tube.
- 13. Connect replacement high voltage cable to laser tube.
- 14. Slide tube back into housing.
- 15. Tighten tube mounts.
- 16. Remount front cap on laser tube housing.
- 17. Remount rear cap on laser tube housing.
- 18. Connect high voltage cable to high voltage power supply.
 19. Remove shorting bar.
- 20. Connect main power.
- 21. Energize laser.
- 22. Review laser system service manual.



PERFORMANCE OBJECTIVE NO. 70

TASK: Replace high voltage cable(s) (Continued)

- 23. Listen for arcing. Proceed as follows if arcing is present.
 - a. Ensure that all cables are away from grounding surfaces.
 - b. Check potting compound for breakdown or degradation.(1) Repair if necessary.
 - c. Troubleshoot excitation system.
- 24. Remove safety glasses.
- 25. Return laser system to service.
- 26. Prepare service report.
- 27. Dispose of defective cable according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 71

TASK: Replace defective resistor(s)

Defective resistor must be soldered in place using STANDARD: resistor with values as specified in laser system

service manual. All soldered joints must be smooth

and shiny.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage probe

Laser system service manual

Resistors Safety glasses

Service report

Shorting bar Solder

Soldering iron Srlder puller

MOV

- 1. Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove high voltage power supply from extrusion.
- 8. Heat soldered joints of defective resistor.
- 9. Remove solder.
- 10. Remove defective resistor from circuit.
- 11. Install replacement resistor in circuit using laser system specifications for resistor value.
- 12. Solder resistor in circuit.
- 13. Return high voltage power supply to extrusion.
- 14. Remove shorting bar.
- 15. Connect main power.
- 16. Energize laser.
- 17. Measure high voltage output.
 - a. Adjust voltage to meet laser system specifications.
- 18. Remove safety glasses.



PERFORMANCE OBJECTIVE NO. 71

TASK: Replace defective resistor(s) (Continued)

- 19. Return laser system to service.
- 20. Prepare service report.
- 21. Dispose of defective resistor(s) according to facility procedure.

SCURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 72

TASK: Replace defective fuse(s)

STANDARD: Defective fuse must be replaced with fuse of current

and voltage rating specified in laser system specifica-

tions. Power supply must operate in conformance

with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Fuse pullers Fuses High voltage probe Laser system service manual Safety glasses Service report Shorting bar

VOM

- Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove power supply from extrusion.
- 8. Remove defective fuse from fuse holder.
- 9. Review laser system specifications.
- 10. Install new fuse in fuse holder with voltage and current rating in accordance with laser system specifications.
- 11. Return power supply to extrusion.
- 12. Remove shorting bar.
- 13. Connect main power.
- 14. Energize laser.
- Check power supply operation. Proceed as follows if power supply does not operate in accordance with laser system specifications.
 - a. Verify that fuse replacement meets laser system specifications.
 - b. Check boards supplied by low voltage power supply for shorts.
 - c. Troubleshoot low voltage power supply.



PERFORMANCE OBJECTIVE NO. 72

TASK: Replace defective fuse(s) (Continued)

- 16. Remove safety glasses.17. Return laser system to service.
- 18. Frepare service report.
- 19. Dispose of defective fuse(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 73

TASK: Replace three-phase contactor

STANDARD: Contactor must be secure in mount. All hook up wires

must be mechanically and electrically mounted.

Wiring must not be frayed.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses Contactor Service report High voltage probe Shorting bar Laser system service manual

- 1. Put on safety glasses.
- 2. Shut down complete laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to contactor.
- 8. Remove contactor solenoid energizer wires.
- 9. Remove contactor phase power wires.
- 10. Remove contactor mounting screws.
- 11. Remove contactor from system.
- 12. Install new contactor.
- 13. Connect phase power lines.
- 14. Connect solenoid energizer wires.
- 15. Remove shorting bar.
- 16. Connect main power.17. Energize system.
- 18. Test high voltage power supply.
 - Adjust voltage to conform with recommended range in laser system service manual.
- 19. Remove safety glasses.



PERFORMANCE OBJECTIVE NO. 73

TASK: Replace three-phase contactor (Continued)

- 26. Return laser system to service.
- 21. Prepare service report.
- 22. Dispose of defective contactor according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 74

TASK: Replace high voltage dump contactor

STANDARD: High voltage dump contactor wires must be soldered in place and ground wire must be connected. All soldered joints must be smooth and shiny. Contactor must discharge high voltage power supply when de-

activated.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
High voltage contactor
High voltage probe
Safety glasses
Service report

Shorting bar Solder Soldering iron Solder puller VOM

PERFORMANCE GUIDE:

1. Put on safety glasses.

- 2. Shut down complete laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to high voltage dump contactor.
- 8. Unsolder and remove high voltage wire from contactor.
- 9. Unsolder and remove two low voltage solenoid wires.
- 10. Disconnect ground wire.
- 11. Remove dump contactor from bracket.
- 12. Flace new dump contactor in bracket and screw into place.
- 13. Solder high voltage wire on to contactor.
- 14. Solder two low voltage wires to contactor solenoid.
- 15. Connect ground wires.
- 16. Remove shorting bar.
- 17. Connect main power.
- 18. Energize laser.
- 19. Check operation of contactor.
 - a. Troubleshoot excitation system if necessary.



PERFORMANCE OBJECTIVE NO. 74

TASK: Replace high voltage dump contactor (Continued)

- 20. Remove safety glasses.
- 21. Return laser system to service.
- 22. Prepare service report.23. Dispose of defective high voltage dump contactor according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 75

TASK: Replace capacitor(s)

STANDARD: Capacitor must be soldered in circuit and installed

according to laser system service manual. Soldered

joints must be smooth and shiny.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Capacitor(s)
High voltage probe
Laser system service manual
Safety glasses
Service report
Shorting bar
Solder
Solder puller
VOM
Wire cutters

- Put on safety glasses.
- 2. Shut down laser power supply.
- Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove high voltage power supply from extrusion.
- 8. Heat soldered joints of defective capacitor.
- 9. Remove solder.
- 10. Remove defective capacitor from circuit.
- 11. Install replacement capacitor in circuit according to laser system specifications.
- 12. Solder capacitor in circuit.
- 13. Return power supply to extrusion.
- 14. Remove shorting bar.
- 15. Connect main power.
- 16. Energize laser.
- 17. Check low voltage power supply operation.
 - a. Troubleshoot low voltage power supply if necessary.
- 18. Remove safety glasses.



PFRFORMANCE OBJECTIVE NO. 75

TASK: Replace capacitor(s) (Continued)

- 19. Return laser system to service.
- 20. Prepare service report.
- 21. Dispose of defective capacitor(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 76

TASK: Replace diode(s)

STANDARD: Diodes must be in place and must be soldered smooth

and shiny. Low voltage power supply wire must be connected. Polarity must be in conformance with laser

system service manual specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Shorting bar Diode(s) Solder

High voltage probe Soldering iron Laser system service manual Solder puller Safety glasses VOM

Service report

- Review laser system service manual.
- 2. Put on safety glasses.
- 3. Shut down laser power supply.
- 4. Disconnect main power.
- 5. Insert shorting bar.
- 6. Attach laser power meter.
- Measure voltage remaining in system CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 8. Disconnect wires from low voltage power supply.
- 9. Remove power supply from extrusion.
- 10. Heat soldered joints.
- 11. Remove solder.
- 12. Remove defective diode.
- 13. Install replacement diode in circuit according to laser system specifications.
- 14. Solder diode in circuit.
- 15. Return power supply to extrusion.
- 16. Remove shorting bar.
- 17. Reconnect low voltage power supply wires.
- 18. Check low voltage power supply operation.
 - a. Tighten wire connections, or
 - b. Adjust power input until it is in conformance with laser system specifications.



PERFORMANCE OBJECTIVE NO. 76

TASK: Replace diode(s) (Continued)

- 19. Remove safety glasses.
- 20. Return laser system to service.
- 21. Prepare service report.22. Dispose of defective diode(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 77

TASK: Replace low voltage power supply

Input wires must be connected to transformer and out-STANDARD:

put wires must be connected to low voltage power

supply. Power must be adjusted to voltage recommended

in laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses High voltage probe Service record Laser system service manual Shorting bar Low voltage power supply MOV

- Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Disconnect wires from low voltage power supply.
- 8. Remove defective power supply from system.
- 9. Connect input wires (AC) to transformer.
- 10. Reconnect output wires (DC) to low voltage power supply.
- 11. Remove shorting bar.
- 12. Connect main power.13. Energize laser.
- 14. Review laser system service manual,
- 15. Attach VOM.
- 16. Measure output of low voltage power supply.
 - a. Adjust voltage up or down until it is in conformance with laser system specifications.
- 17. Remove VOM.
- 18. Remove safety glasses.



PERFORMANCE OBJECTIVE NO. 77

TASK: Replace low voltage power supply (Continued)

- 19. Return laser system to service.
- 20. Prepare service report.
- 21. Dispose of defective low voltage power supply according to facility procedure.

SOURCE FOR STANDARD:



DUTY: REPAIRING LOW VOLTAGE POWER SUPPLY

PERFORMANCE OBJECTIVE NO. 78

TASK: Replace transformer

STANDARD: Transformer must be soldered smooth and shiny, in

circuit with secondary and primary wiring in conform-

ance with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
High voltage probe
Laser system service manual
Solder puller
Safety glasses
Service report
Shorting bar
Solder younger
Solder puller
Transformer
VOM
Wire

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove power supply cover.
- 8. Remove power supply.
- 9. Heat solder joints on defective transformer.
- 10. Remove solder.
- 11. Wire transformer, secondary and primary according to laser system specifications.
- 12. Place transformer in power supply circuit.
- 13. Solder transformer in circuit.
- 14. Return power supply to extrusion.
- 15. Replace and secure power supply cover.
- 16. Remove shorting bar.
- 17. Check low voltage power supply operation.
 - a. Troubleshoot low voltage supply if operation is not in conformance with laser system specifications.

DUTY: REPAIRING LOW VOLTAGE POWER SUPPLY

PERFORMANCE OBJECTIVE NO. 78

TASK: Replace transformer (Continued)

- 18. Remove safety glasses.
- 19. Return laser system to service.
- 20. Prepare service report.
- 21. Dispose of defective transformer according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 79

TASK: Replace RF cable connector(s)

STANDARD: Center pin must be soldered smooth and shiny to cable end and center pin must be seated into RF connector. Cable connector(s) must be attached according to laser system service manual specifications. All cable shields must be braided according to manufacturer's instructions. Cable must be attached between RF driver and Q-switch without

arcing or shorting.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit
Crimp tool
High voltage probe
Laser system service manual
Manufacturer's instructions
for RF cable connector
Ohmmeter

RF cable connector Safety glasses Service report Shorting bar Solder Soldering iron

- Put on safety glasses.
- 2. Shut down RF driver.
- 3, Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove RF cable from driver to Q-switch.
- 8. Cut defective connector off of RF cable.
- 9. Attach replacement cable connector according to laser sys tem service manual.
- 10. Braid cable shields according to manufacturer's instruc-
- 11. Attach ohmmeter.
- 12. Check between center pin and outer shield for any possible short.
 - a. Repeat steps #7-10 if cable is shorted.

PERFORMANCE OBJECTIVE NO. 79

TASK: Replace RF cable connector(s) (Continued)

- 13. Connect cable back between RF driver and Q-switch.
- 14. Remove shorting bar.
- 15. Connect RF driver power.
- 16. Remove safety glasses.17. Return laser system to service.
- 18. Prepare service report.
- 19. Dispose of defective RF cable connector according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 80

TASK: Replace RF driver

STANDARD: Controller box, RF output and low voltage supply

must all be connected to RF driver. Heat sink compound must be smoothly and evenly distributed

across back of RF driver box.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Heat sink compound High voltage probe Safety glasses Service report Shorting bar VOM

- 1. Put on safety glasses.
- 2. Shut down RF driver.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Remove connector from RF driver to controller box.
- 8. Remove RF output connector.
- 9. Remove power connector from low voltage supply to RF driver.
- Remove mounting screws from bulkhead wall to RF driver box.
- 11. Remove RF driver box.
- 12. Apply heat sink compound to back of replacement RF driver box.
 - Note: Spread compound evenly across surface.
- 13. Mount replacement driver onto bulkhead wall with mounting screws.
- 14. Tighten down replacement driver.
- 15. Reconnect controller box connector to RF driver.
- 16. Reconnect RF output connector.
- Reconnect RF low voltage power supply connector to RF driver.
- 18. Remove shorting bar.



PERFORMANCE OBJECTIVE NO. 80

TASK: Replace RF driver (Continued)

- 19. Turn RF power back on.
- 20. Remove safety glasses.
- 21. Return laser system to service.22. Prepare service report.
- 23. Dispose of defective RF driver according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 81

TASK: Replace vacuum pump

Mounting bolts, vacuum input hose, power cable, and STANDARD:

exhaust line must be secure in system. Oil level and operation of vacuum pump must be in conformance

with laser system specifications.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage probe Laser system service manual 0i1

Safety glasses

Service report Shorting bar Vacuum pump MOV

- 1. Put on safety glasses.
- 2, Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to vacuum pump.
- 8. Wipe area clean with rag.
- Disconnect pump input hose.
- 10. Label cable wires before disconnecting to maintain phase relationships.
- 11, Disconnect pump power cable.
- 12. Disconnect pump exhaust line.
- 13. Remove pump mounting bolts.
- 14. Remove pump from system.
- 15. Check new pump for oil level.
 - a. Add oil to level recommended in laser system service
- 16. Place new pump in laser system.



PERFORMANCE OBJECTIVE NO. 81

TASK: Replace vacuum pump (Continued)

- 17. Reinstall mounting bolts.
- 18. Tighten bolts.
- 19. Connect vacuum input hose.
- 20. Connect power cable according to labeling on wires.
- 21. Connect exhaust line.
- 22. Remove shorting bar.
- 23. Connect main power.
- 24. Energize laser.
- 25. Test laser vacuum system.
 - a. Troubleshoot vacuum system if necessary.
- 26. Purge vacuum system.
- 27. Remove safety glasses.
- 28. Return laser system to service.
- 29. Prepare service report.
- 30. Dispose of defective vacuum pump according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 82

TASK: Replace vacuum hose(s)

STANDARD: Vacuum hose end(s) must be cleanly cut and hose

clamp(s) must be secure on fitting(s). Vacuum grease must be applied evenly and without caking. Vacuum

system must be purged and must not leak.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage probe Oscilloscope Safety glasses Service report Shorting bar Tape measure Vacuum hose Vacuum grease

- 1. Put on safety glasses.
- 2. Shut down laser power supply.
- 3, Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to defective vacuum hose(s).
- Remove hose and clamps.
- 9, Measure and cut new lengths of hose.
- 10. Pull hose clamps off old hose.
- 11. Put new clamps on hose.
- 12. Insert new hose back in system.
- 13, Apply thin coat of vacuum grease on end of each fitting.
- 14. Push hose back on fittings.
- 15. Tighten hose clamps.
- 16. Remove shorting bar.
- 17. Connect main power.
- 18. Energize laser.



PERFORMANCE OBJECTIVE NO. 82

TASK: Replace vacuum hose(s) (Continued)

- 19. Check vacuum system for leaks.
 - a. lighten hose clamps if necessary.
- 20. Purge vacuum system.
- Remove safety glasses.
- 22. Return laser system to service.
- 23. Prepare service report.
- 24. Dispose of defective vacuum hose(s) according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 83

TASK: Purge vacuum system

STANDARD: Vacuum system must be free of contaminated gas and

must be filled with gas specified in laser system

service manual.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Laser system service manual Safety glasses Service report

PERFORMANCE GUIDE:

- 1. Review laser system service manual.
- 2. Put on safety glasses.
- Energize laser system. CAUTION: DC NOT ACTIVATE HIGH VOLTAGE.
- 4. Turn off all gas supply valves.
 CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS CLOSED
 AND GAS BOTTLE IS SECURE.
- 5. Turn on vacuum pump.
- Run vacuum pump until pressure is stabilized and within laser system specifications for evacuated system.
 - Troubleshoot vacuum system if specified pressure cannot be achieved.
- 7. Fill laser to pressure and composition specified in laser system service manual.
- 8. Remove safety glasses.
- 9. Return laser system to service.
- 10. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 84

TASK: Change vacuum pump oil

STANDARD: Vacuum pump must be replenished to sight glass with

oil weight recommended in laser system specifications.

Drain oil plug must be replaced and all spilled oil

Drain oil plug must be replaced and all spilled oil

must be removed.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses
High voltage probe Service report
Laser system service manual Shorting bar
Oil pan Vacuum pump oil

PERFORMANCE GUIDE:

- 1. Put on safety glasses.
- 2. Energize laser.
- 3. Run laser for 10 minutes.

Note: Laser system components must be warm.

- 4. Shut down laser system.
- 5. Disconnect main power.
- 6. Insert shorting bar.
- Attach high voltage probe.
- 8. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 9. Gain access to vacuum pump.
- 10. Wipe vacuum pump clean with rag.
- 11. Remove vacuum pump oil fill cap.
- 12. Place oil pan under vacuum pump.
- 13. Remove drain oil plug.
- 14. Drain oil into oil pan.
- 15. Replace drain oil plug.
- 16. Fill pump with new oil up to sight glass.
- 17. Replace oil fill cap.
- 18. Clean up any spilled cil.
- 19. Remove shorting bar.



PERFORMANCE OBJECTIVE NO. 84

TASK: Change vacuum pump oil (Continued)

- 20. Connect main power.
- 21. Remove safety glasses.
- Return laser system to service.Prepare service report.
- 24. Dispose of drained oil according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 85

TASK: Replace gas flow gauge(s)

STANDARD: Gas flow gauge(s) must be secure in mount and must

not leak gas.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Flow gauge(s) High voltage probe Laser system service manual manufacturer's specified Safety glasses

Service report Shorting bar Spray bottle containing leak detector

- Put on safety glasses.
- 2. Shut down laser power supply.
- 3. Disconnect main power
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- Turn off main gas supply valve. CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS CLOSED AND GAS BOTTLE IS SECURE.
- Gain access to gas flow gauge(s).
- 9. Wipe area clean with rag.
- 10. Remove inlet and outlet gas lines.
- 11. Remove gauge(s) from system.
- 12. Wash hands.
- 13. Connect new gauge(s) in system mount.
- Connect gas inlet and outlet lines. 14. Note: Be careful not to cross thread fitting(s).
- 15. Turn on gas supply valve.
- 16. Remove shorting bar.
- 17. Energize laser.



PERFORMANCE OBJECTIVE NO. 85

TASK: Replace gas flow gauge(s) (Continued)

- 18. Test flow gauge(s) for gas leaks and operation.
- 19. Remove safety glasses.
- 20. Return laser system to service.
- 21. Prepare service report.
- 22. Dispose of defective gas flow gauge according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 86

TASK: Replace gas solenoid(s)

STANDARD: Gas solenoid(s) must be secure in mount. Hook up

wires must be mechanically and electrically secure.

Solenoid must not leak gas.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses
Gas solenoid(s) Service report
High voltage probe Shorting bar
Laser system service manual Teflon tape
Leak test liquid VOM

- 1. Put on safety glasses.
- 2. Shut down complete laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Turn off main gas supply valve.
 CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS CLOSED AND GAS BOTTLE IS SECURE.
- 8. Gain access to gas solenoid(s).
- 9. Clean area with rag.
- 10 Remove solenoid electrical wires.
- II Remove inlet and outlet gas supply lines.
- 12. Remove gas solenoid from system.
- 13. Wash hands.
- 14. Install new gas solenoid in mounting bracket.
- 15. Connect gas inlet and outlet lines. Note: Be careful not to cross thread fittings.
- 16. Wrap fitting threads with teflon tape.
- 17. Connect electrical wires to solenoid.
- 18. Turn on gas supply valve.
- 19. Remove shorting bar.



PERFORMANCE OBJECTIVE NO. 86

TASK: Replace gas solenoid(s) (Continued)

- 20. Energize laser.
- 21. Test gas solenoid for gas leaks and operation.
 a. Troubleshoot gas supply system if necessary.
- 22. Remove safety glasses.
- 23. Return laser system to service.
- 24. Prepare service report.
- 25. Dispose of defective gas solenoid according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 37

TASK: Repair gas leak(s)

STANDARD: Laser system must pass manufacturer's gas leak test.

All fittings and clamps must be tight and 0-rings must be replaced. Punctured hosing must be repaired

or replaced.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit High voltage probe

Hosing

Laser system service manual Leak test liquid

0-rings

Safety glasses Service report

Silicone vacuum greaser

Shorting bar

MOV

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system. CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to gas leak area.
- 8. Identify gas leak source.
 - a. Hose clamp
 - b. O-ring fitting(s) in couplingc. Metal fitting(s)

 - d. Gas hose puncture.
- 9. Tighten leaking hose clamps.
- 10. Replace O-rings.
- 11. Tighten metal fittings.
- 12. Repair or replace punctured gas hosing.
- 13. Remove shorting bar.
- 14. Connect main power.



PERFORMANCE OBJECTIVE NO. 87

TASK: Repair gas leak(s) (Continued)

- 15. Energize laser.
- 16. Test system for gas leaks according to laser system service manual.
 - a. Repair gas leak(s) if necessary.
- 17. Remove safety glasses.
- 18. Return laser system to service.
- 19. Prepare service report.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 88

TASK: Replace gas regulator(s)

STANDARD: Gas fitting must not be leaking and gas regulator

must be adjusted to system operating pressure.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses
Gas regulator(s) Service report
High voltage probe Shorting bar
Laser system service manual VOM

Leak test liquid

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to gas regulator(s).
- 8. Shut off main gas supply valve. CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS CLOSED AND GAS BOTTLE IS SECURE.
- 9. Remove gas inlet hose.
- 10. Remove gas outlet hose.
- 11. Remove gas regulator low pressure electrical switch.
- 12 Remove regulator from mounting bracket.
- 13 Install new gas regulator in mounting bracket.
- 14. Connect inlet gas hose.
- 15. Purge gas regulator.
- 16 Connect outlet gas hose.
- 17. Connect low pressure electrical switch.
- 18, Remove shorting bar.
- 19. Connect main power.
- 20 Energize laser.
- CAUTION: DO NOT TURN ON HIGH VOLTAGE.



PERFORMANCE OBJECTIVE NO. 88

TASK: Replace gas regulator(s) (Continued)

- 21. Turn on gas supply valve.
- 22. Test regulator for gas leaks.
 - a. Repair gas leaks if necessary.
- 23. Adjust gas regulator output pressure to laser system specifications.
- 24. Remove safety glasses.
- 25. Return laser system to service.
- 26. Prepare service report.
- 27. Dispose of defective gas regulator according to facility procedure.

SOURCE FOR STANDARD:



PERFORMANCE OBJECTIVE NO. 89

TASK: Purge gas regulator(s)

STANDARD: Regulator must be free of any airborn contaminants.

CONDITIONS FOR PERFORMANCE OF TASK:

Standard tool kit Safety glasses Gas regulator(s) Service report High voltage probe Shorting bar Laser system service manual VOM

- 1. Put on safety glasses.
- 2. Shut down laser system.
- 3. Disconnect main power.
- 4. Insert shorting bar.
- 5. Attach high voltage probe.
- 6. Measure voltage remaining in system.
 CAUTION: DO NOT PROCEED UNTIL ALL VOLTAGE HAS BEEN DRAINED FROM SYSTEM.
- 7. Gain access to gas regulator(s).
- 8, Shut off main gas supply valve.
 CAUTION: DO NOT PROCEED UNTIL SHUT-OFF VALVE IS CLOSED AND GAS BOTTLE IS SECURE.
- 9. Remove gas inlet hose.
- 10. Remove gas outlet hose.
- 11. Remove regulator from mounting bracket.
- 12. Remove gas regulator low pressure electrical switch.
- 13 Install new gas regulator in mounting bracket.
- 14 Connect inlet gas hose.
- Review laser system service manual for precautions when working within gas system.
- 16. Turn pressure adjusting screw control until control feels free of internal spring.
- 17. Close flow control valve located on output side of regulator.
- Open cylinder valve and observe pressure on high pressure gauge.
- 19. Close cylinder valve.
- 20. Open control valve 1/2 turn.



PERFORMANCE OBJECTIVE NO. 89

TASK: Purge gas regulator(s) (Continued)

- 21. Turn pressure adjusting screw control until pressure on high pressure gauge returns to zero.
- 22. Repeat steps #16-21 two more times.
- 23. Remove shorting bar.
- 24. Remove safety glasses.
- 25. Return laser system to service.
- 26. Prepare service report.

SOURCE FOR STANDARD:



APPENDICES



Appendix A

Standard Tool Kit Contents

The components of the standard tool kit referred to in the majority of the performance objectives in this catalog was compiled by the Writing Team. It consists of the following tools, equipment, and work aids.

Alignment tool Assorted screwdrivers Allen Flat blade Phillips | Assorted wrenches Cresent set Combination Open-end Spanner Brushes Acid Dusting Burnisher Clean rags Digital cutters Electrical tape Feeler gauge set Files Flat Round Swiss pattern Taper Flashlight or penlight Forceps

Hammer Hemostat Hex key set Laser rod O-ring set Laser safety goggles Mode selector Nut driver Pliers. Diagonal Chain nose Long chain Needle nose Slipjoint Utility Pocketknife or utility blade Safety glasses Scale (6" Eng/meter) Socket set Solder. Splice key set Tweezers Wire cutters Wire strippers

A field service laser systems technician may also carry the tools and equipment listed below which may not be readily available to the technician in the field. These have been listed separately in the Performance Objective of each task.

Cross hair
Duster
Energy meter/power meter
High voltage probe
High voltage shorting bar
Lamp extractor tool
Lamp socket tool

Mirror holder device
Mirror retainer removal tool
Pulse detector
Soldering iron
Solder puller
Teflon tape
VOM



Appendix B Tools/Equipment/Work Aids by Percent of Laser Systems Technician Using (n = 17)

Tools/Equipment/Work Aids	Percent Using
Adjustable wrench	100.0
Allen wrench	100.0
Beamsplitter	100.0
Laser power/energy meter	100.0
Lens mount	100.0
Lens tissue	100.0
Methyl alcohol	100.0
Microscope	100.0
Mirror	100.0
Mirror mount	100.0
Oscilloscope	
Phillips screwdriver set	100.0
Pliers	100.0
Screwdriver	100.0
	100.0
Tweezers Wire cutters	100.0
	100.0
Ammeter	94.1
Angular adjustment mount	94.1
Focusing lens	94.1
Helium-neon laser	94.1
Lens cleaner	94.1
Mirror holder	94.1
Multimeter	94.1
Ohmmeter	94.1
Tape	94.1
Voltmeter	94.1
Jack stand	88.2
Lens cloth	88.2
Micrometer	88.2
Optical bench	88.2
Polarizer	88.2
Power meter	88.2
Pulse generator	88.2
Scissors	88.2
Spanner wrench Water flow meter	88.2
Expander lens	88.2
Hammer	82.4
Mirror retainer remover	82.4
Prism	82.4
Socket assembly set	82.4
Socret assembly ser	82.4



Tools/Equipment/Work Aids	Percent Using
Water pressure gauge	82,4
Amplifier	76.5
Compressed air	76.5
Digital energy meter	76.5
Frequency counter	76.5
High voltage capacitator	76,5
IR card	76.5
Safety filter goggles	76.5
Collimator	70.6
Color glass filter	70.6
Function generator	70.6
Fuse kit	70.6
High energy capacitator	70.6
H.V. shorting bar	70.6
Interferometer	70.6
Laser mount	70.6
Neutral density filter	70.6
Optical power meter	70.6
Optical spectrum analyzer	70.6
Photiodiode detector	70.6
Vibration free table	70.6
Water purity meter	70.6
Electro-optic modulator	64.7
Green phosphor screen	64.7
Mode selector	64.7
Optical table	64.7
Spe trum analyzer	64.7
Ultraviolet light	64.7
Acousto-optic modulator	58.8
Autocalameter	58.8
Calorimeter	58.8
Precision laboratory microscope	58.8
Signal generator	58.8
VTVM	58.8
Bird RF meter	52.9
CRI mount	52,9
Dummy load	52.9
Gauge block	52.9
Optical component tester	52.9
Prism table	52.9
Wattmeter	52.9
Digital electronic pulser	47.1
Electrically conducting adhesive	47.1
O-ring seating tool	47.1
RF generator	47.1
Stereo microscope	47.1
İ	



Tools/Equipment/Work Aids	Percent Using
Commonpath interferometer	41.2
Glass-to-metal adhesive	41.2
Quartz halogen power supply	41.2
Spectral analyzer	41,2
Wheatstone bridge	41.2
Crystal location tool	35.3
Galvonometer	35.3
Lamp extractor tool	35.3
Lamp socket tool	35.3
Optical encoder	35.3
Rear detector	35.3
Testtape	35.3
Laser safety monitor	29.4
Quartz halogen housing	29.4
Quartz halogen lamp	29.4
Wedge angle measurement device	29.4
Dye laser pump	23.5
LED tester	23.5
Photon drag detector	23.5
Toolmaker's microscope	23.5
Borescope	11.8
Faraday rotator	11.8
· m· mmg · · www.wwi	1 1110

These tools, equipment and work aids have been added as a result of further input from the Writing and Review Teams and from the results of write-ins on the occupational inventory.

Air hood
Alignment tool
Combination wrench
Compressed air
Cresent wrench
Cross hair
Digital cutters
Dusting brush
Feeler gauge set
Flashlight
Flat file
Forceps
Hemostat
Hex key set

Nut driver
Open-end wrench
Round file
Safety glasses
Scale (6" Emg/meter)
Solder
Soldering iron
Solder puller
Splice key set
Swiss pattern file
Taper file
Vacuum fore pump
Wire strippers



Appendix C

Bibliography: Sources of Standards

1 Writing Team of Incumbent Workers
Consensus of incumbents in laser technology

- . laser technician
- . laser systems technician
- . laser systems field service technician



APPENDIX D

Cross-Reference Table

This V-TECS catalog is a cumulation of research activities resulting in a description of the following domain area in terms of occupational-related duties, tasks, performance objectives, and performance guides.

Laser Technician DOT: 019.181-010

Laser Systems Technician
DOT: N/A

The following legend for the cross-reference table codes the results of a task analysis from inventory development, to incumbent survey, to data analysis, to catalog completion.

- 1. n The n accompanying an occupational title is the number of respondents to the occupational survey.
- Column and row percentage indicate survey responses of performance of a task by incumbents.
- 3. # Indicates a write-in task by incumbents during survey.
- 4. Note Indicates a write-in task to catalog by incumbents during development of catalog. Note indicates no data collected during survey.
- 5. (task) Indicates that consensus of incombents was used to reword or edit task statement from original task in inventory. Task in parenthesis is the original task.



- 6. subscripts Subscripts are used to indicate subdivision of original task into two or more tasks based upon review and consensus of incumbent workers.
- 7. (task, letter Indicates task includes one or more original number) tasks in criginal inventory.
- 8. (see task, Task(s) cross-listed into another task(s).
 letter,number)
- 9. @ An @ indicates accompanying materials are needed and are included in the catalog.
- 10. * Based on analysis of survey data, no performance objective written.

CROSS-REFERENCE TABLE

Laser Systems Technician

Laser Technician DOT: 019.181-010

Laser Systems Technician DOT: N/A

Respondents: n = 17

Duties		Tasks	Performance Objective/ Page Numbers	Percent (%) Performing	
				Laser Tech.	Laser Sys. Tech.
Α.	MAINTAIN	NING RECORDS		İ	
	01	Maintain laboratory notebook	1/1	92.3	75.0
	02	Prepare operational log book	2/2		
		(Prepare technical report)		77.0	100.0
	03	Prepare shop drawing(s)	3/3		
		(Prepare shop drawing)		84.7	75.0
	04	Prepare equipment requisition	4/4	92.3	100.0
	05	Prepare service report	5/5	38.4	75.0
	06	Prepare expense report	6/6	53.9	75.0
	07	Update technical manual	7/7	53.9	75.0
В.	INSTALLI	NG LASER SYSTEMS			
	01	Install gaseous laser system	8/8	30.8	50.0
	02	Install solid state (YAG) laser system	9/10	61.6	50.0
С.	MAINTAIN	IING LASER SYSTEMS			
	01	Inspect reflecting mirrors and focusing optics	10/13	100.0	100.0



Duties	Outies Tasks		Percent (%) Performing	
			Laser Tech.	Laser Sys Tech.
C. MAINTAIN	ING LASER SYSTEMS (CONTINUED)			
02	Clean optics	11/14	100.0	100.0
03	Verify Q-switch in YAG laser system	12/16	69.2	50.0
04	Verify polarizer in YAG laser system	13/18	61.6	50.0
05	Test power/energy output at source	14/20		
	(Test power output at source)		92.3	100.0
06	Verify thermal switch operation	15/21	53.9	75.0
07	Test RF power on Q-switch	16/22	69.2	50.0
08	Change water filter	17/23	100.0	100.0
09	Change deionizer cartridge holder	18/24		
	(Change deionizer cartridge)		92.3	100.0
10	Adjust power supply output	19/26		
	(Calibrate power supply output)		53.4	50,0
11	Align complete beam delivery path	20/28		
	(Align complete optics path)		100.0	100.0
	Align cavity optics	21/29	Note	Note
12	Inspect cooler fittings	22/32	100.0	100.0
13	Inspect air circulating filter(s)	23/33	61.6	75.0



	Duties Tasks		Performance Objective/ Page Numbers	Percen Perfor	
				Laser Tech.	Laser Sys. Tech.
C.	MAINTAIN	ING LASER SYSTEMS (CONTINUED)			
	14	Clean air circulating filter(s)	24/35	53.9	75.0
	15	Replace air circulating filter(s)	25/36	53.9	75.0
	16	Measure power/energy output at source	26/37		w
		(Measure power output at source)		92.3	100.0
	17	Verify safety interlock system operation	27/38	92.3	75.0
	18	Verify lens focal length	28/39	100.0	0,001
	19	Verify repetition rate	29/40		
		(Verify rep rate)		84.7	100.0
D.	ANALYZIN	G DOWN LASER SYSTEMS			
	10	Identify symptoms of problem	30/41	100.0	100.0
	02	Troubleshoot temperature control system	31/42	77.0	75.0
	03	Troubleshoot beam genera- tion system	32/44	92.3	100.0
	04	Troubleshoot excitation system	33/46	92.3	100.0
	05	Troubleshoot low voltage power supply	34/48	77.0	50.0
	06	Troubleshoot RF system	35/50	61.6	75 - 0



Duties		uties Tasks	Performance Objective/ Page Numbers	Percent (%) Performing	
	-			Laser Tech.	Laser Sys. Tech.
D.	ANALYZIN (CONTINU	G DOWN LASER SYSTEMS ED)			
	07	Troubleshoot vacuum system	36/52	30.8	50.0
	08	Troubleshoot gas supply system	37/54	30.8	50.0
Ε.	REFAIRIN	G TEMPERATURE CONTROL SYSTEM			
	01	Replace cooler fitting(s)	38/56	92.3	100.0
	02	Clean cooler fitting(s)	39/58	84.7	100.0
	03	Recharge cooling system	40/60	53.9	75 .0
	04	Replace temperature sensor(s)	41/62	69,2	75.0
	05	Replace defective water pump	42/64	92.3	100.0
	06	Replace flow sensor	43/66		
		(Replace flow sensor switch)		92.3	0.001
	07	Repair defective wiring	44/68	84.7	75 . 0
	08	Replace defective hosing	45/70	84.7	100.0
	09	Replace heat exchanger	46/72	69.2	75.0
	10	Replace reservoir level switch	47/74	46.1	100.0
	11	Replace agitator	48/75	30 , 8	75.0
	12	Replace water solenoid(s)	49/76	53.9	50.0
F,	REPAIRIN	G BEAM GENERATION SYSTEM			
	01	Replace crystal rod	50/78	77.0	50,0



	Duties	Tasks	Performance Objective/ Page Numbers	Percei Perfo	nt (%) rming
				Laser Tech.	Laser Sys. Tech.
F.	REPAIRIN (CONTINU	G BEAM GENERATION SYSTEM ED)			
	02	Replace gaseous tube	51/81	30.8	50.0
	03	Replace mirror(s)	52/84	100.0	100.0
	04	Replace gold cavity	53/85	61.6	50,0
	05	Replace electrodes	54/87	84.7	75.0
	06	Replace polarizer	55/89	69.2	50.0
	07	Replace Q-switch	56/90	77.0	50.0
	08	Repair beam expander	57/92	77.0	50.0
	09	Replace mirror mount	58/93	100.0	75.0
	10	Replace laser housing assembly	59/94	92.3	50.0
	11	Replace flash lamp	60/96	77.0	50.0
	12	Replace lamp jacket	61/98	77.0	50.0
	13	Collimate beam expander	62/100	92.3	75.0
	14	Verify peak pulse power	63/102	92.3	100.0
	15	Verify frequency of pulse train	64/103	100.0	50.0
G	REPAIRIN	G EXCITATION SYSTEM			
	01	Replace high voltage capacitors	65/105	53.9	100.0
	02	Replace high voltage diodes	66/107	84.7	75 0
	63	Replace SCR (silicon control rectifier)	67/109	69.2	75.0



Duties		uties Tasks Performance Objective/ Page Numbers	Objective/ Performing		• •
_	-			Laser Tech.	Laser Sys. Tech.
G.	REPAIRIN (CONTINU	G EXCITATION SYSTEM			
	04	Replace defective board(s)	68/111	84.7	25.0
	05	Repair defective board(s)	69/112	84.7	25.0
	06	Replace high voltage cable(s)	70/113	100.0	75.0
	07	Replace defective resistor(s)	71/115	92.3	75.0
	08	Replace defective fuse(s)	72/117	92.3	75.0
	09	Replace three-phase contactor	73/119	46.1	75.0
	10	Replace high voltage dump contactor	74/121	38.4	50.0
Н.	REPAIRIN	G LOW VOLTAGE POWER SUPPLY			
	01	Replace capacitor(s)	75/123	61.6	75.0
	02	Replace diode(s)	76/125	61.6	75.0
	03	Replace low voltage power supply	77/127	61.6	25.0
	04	Replace transformer	78/129	61 - 6	75.0
Ι.	REPAIRIN	G RF SYSTEM			
	01	Replace RF cable connector(s)	79/131	53.9	75 0
	02	Replace RF driver	80/133	53.9	75.0
J	REPAIRIN	G VACUUM SYSTEM			
	01	Replace vacuum pump	81/135	30.8	50.0
	02	Replace vacuum hose(s)	82/137	30.8	50.0



	Duties	Tasks	Performance Objective/ Page Numbers	Percer Perfor	•
				Laser Tech.	Laser Sys. Tech.
J.	REPAIRING VA	ACUUM SYSTEM			
	03 Purge va	acuum system	83/139	30.8	50.0
	Change v	acuum pump oil	84/140	Note	Note
Κ.	REPAIRING GA	AS SUPPLY SYSTEM			
	Ol Replace	gas flow gauge(s)	85/142	30.8	50.0
	02 Replace	gas solenoid(s)	86/144	30.8	50.0
	03 Repair 9	gas leak(s)	87/146	23.0	50.0
	04 Replace	gas regulator(s)	88/148	23.0	50.0
	Purge ga	s regulator	89/150	Note	Note



Appendix E

STATE-OF-THE-ART BIBLIOGRAPHY

<u>Duties</u> and <u>Task List Development</u>

- Final Report of Laser/Electro-Optics Technology. Waco, Texas: Technical Education Research Centers, Inc., January, 1975.
- Fioroni, John J. <u>Competency-Based Curriculum Guide for Laser Technology</u>. Springfield, <u>Illinois</u>: <u>Illinois</u> Vocational Curriculum Center.
- International Laser/Electro-Optics Training Conference Proceedings.
 Wausau, Wisconsin: North Central Institute, June, 1980.
- Instruction Manual. Mountain View, California: Spectra-Physics, Inc.
- <u>Laser Electro-Optics Curriculum Guide, Laser/Electro-Optics Technology</u>
 <u>Series</u>. Waco, Texas: Center for Occupational Research and Development, Inc., 1980.
- <u>Laser/Optics: Tomorrow's Technology Today</u>. Cincinnati, Ohio: Cincinnati Technical College.
- Muncheryan, Hrand M. <u>Principles and Practice of Laser Technology</u>. Blue Ridge Summit, Pennsylvania: Tab Book, Inc., 1983.
- Nd: YAG Laser Systems. Smithtown, New York: Quantronix Corporation.

Standards Identification

Writing Team of Incumbent Workers (See Appendix C)

Tools, Equipment, Work Aids Identification

- Electro-Optical Systems Design. Denver, Colorado: Cahners Publishers, October, 1982.
- Fioroni, John J. <u>Competency-Based Curriculum Guide for Laser Technology</u>. Springfield, Illinois: Illinois Vocational Curriculum Center.
- International Laser/Electro-Optics Training Conference Proceedings.
 Wausau, Wisconsin: North Central Institute, June, 1980.



Tools, Equipment, Work Aids Identification (Continued)

- Laser Electro-Optics Curriculum Guide, Laser/Electro-Optics Technology

 Series. Waco, Texas: Center for Occupational Research and Development, Inc., 1980.
- <u>Laser Focus with Fiberoptic Technology</u>. Littleton, Massachusetts:

 PenWell Publishing Company, Advanced Technology Group, March, 1983.
- Laser Focus Buyer's Guide. Littleton, Massachusetts: PenWell Publishing Company, January, 1982.

Writing Team of Incumbent Workers (See Appendix C)



